


digital

fortran IV

**software
support manual**

digital equipment corporation



DEC-S8-LFSSA-A-D

OS/8 FORTRAN IV
SOFTWARE SUPPORT MANUAL

For additional copies, order No. DEC-S8-LFSSA-A-D
from Software Distribution Center, Digital Equipment
Corporation, Maynard, Mass.

digital equipment corporation • maynard. massachusetts

First Printing
June, 1973

Copyright © 1973 by Digital Equipment Corporation

The following are trademarks of Digital Equipment Corporation,
Maynard, Massachusetts:

CDP	DIGITAL	KA10	PS/8
COMPUTER LAB	DNC	LAB-8	QUICKPOINT
COMTEX	EDGRIN	LAB-8/e	RAD-8
COMSYST	EDUSYSTEM	LAB-K	RSTS
DDT	FLIP CHIP	OMNIBUS	RSX
DEC	FOCAL	OS/8	RTM
DECCOMM	GLC-8	PDP	SABR
DECTAPE	IDAC	PHA	TYPESET 8
DIBOL	IDACS		UNIBUS
	INDAC		

CONTENTS

CHAPTER 1	THE F4 COMPILER	1-1
CHAPTER 2	THE RALF ASSEMBLER	2-1
CHAPTER 3	THE FORTRAN IV LOADER	3-1
CHAPTER 4	THE FORTRAN IV RUN-TIME SYSTEM	4-1
CHAPTER 5	LIBRA AND FORLIB	5-1
APPENDIX A	RALF Assembler Permanent Symbol Table	A-1
APPENDIX B	Assembly Instructions	B-1

CHAPTER 1

THE F4 COMPILER

The OS/8 F4 compiler runs in 8K on either a PDP-8 or a PDP-12. It operates in three passes to transform FORTRAN IV source programs into RALF assembly language. The function of each of the three passes is:

1. Analyze statements, check syntax and convert to a polish notation.
2. Convert output of PASS1 to RALF assembly language making extensive use of code skeleton tables.
3. Produce a listing of the FORTRAN source program and/or chain to the assembler.

The following is a more complete description of each of the three passes.

PASS1 OPERATION

After opening the source language input file(s) and an intermediate output file, PASS1 processes statements in the following fashion:

1. Assemble a statement into the statement buffer by reading characters from the OS/8 input file. This section eliminates comments and handles continuations so that the statement buffer contains the entire statement as if it had been written on one long line.
2. The statement is first assumed to be an arithmetic assignment and an attempt is made to compile it as such. This is done with a special switch (NOCODE) set so that in the event the statement is not arithmetic, no erroneous output is produced. Thus, with this switch set, the expression analyzer subroutine is used merely as a syntax checker.
3. If the statement is indeed an arithmetic assignment statement (or arithmetic statement function) the switch is set off and the statement is then recompiled, this time producing output.

4. If not an arithmetic assignment, the statement might be one of the keyword defined statements. The compiler now checks the first symbol on the line to see if it is a legal keyword (REAL, GOTO, etc.) and jumps to the appropriate subroutine if so. Any statement that is not now classified is considered to be in error.
5. The compilation of each statement takes place. Some statements produce only symbol table entries (e.g., DIMENSION) which will be processed by PASS2. Others use the arithmetic expression analyzer (EXPR) and also output special purpose operators which will tell PASS2 what to do with the value represented by the arithmetic expression (e.g., IF, DO).
6. After the statement has been processed, control passes to the end-of-statement routine which handles DO-loop terminations and then outputs the end-of-statement code.
7. Statements containing some kind of error cause a special error code to be output.
8. The entire process is now repeated for the next statement.
9. When the END statement is encountered, PASS1 chains to PASS2.

PASS1 SYMBOL TABLE


A significant portion of the PASS1 processing involves the production of symbol table entries. These entries contain all storage related information, i.e., variable name, type, dimensions, etc.

The symbol table is organized as a set of linked lists. The first 26 such lists are for variables, with the first letter of the variable name corresponding to the ordinal number of the list. There are also separate lists for statement numbers and literals (integer, real, complex, double, and Hollerith). In addition to list elements, there are special entries for holding DIMENSION and EQUIVALENCE information.

A detailed description of each type of entry follows. (NOTE: All symbol table entries are in Field 1.)

1. VARIABLE - The first word of each entry is a pointer to the next entry, with a zero pointer signaling end of list. The second word contains type information. The third word points to the dimension and/or equivalence information blocks. The next one to three words contain the remainder of the name (the first character is implied by which list the entry is in) in stripped six-bit ASCII terminated by a zero character. Thus, shorter variables take less symbol table space. The entries are (as for all lists in the symbol table) arranged in order of increasing magnitude, or alphabetically.

POINTER
 TYPE
 DIMENSION/EQUIVALENCE
 NAME 2-3
 NAME 4-5
 NAME 6



TYPE WORD FORMAT

0	1	2	3	4	5	6	7	8	9	10	11
C O M	D I M	E X T	A S F	E Q U I V	E X P L I C	L I T	A R G	T	Y	P	E


BIT

- ø - Variable is in common.
- 1 - Variable is dimensioned.
- 2 - External symbol or subroutine/function name.
- 3 - Symbol is the name of an arithmetic statement function.
- 4 - Variable is an equivalence slave.
- 5 - Variable is explicitly typed.
- 6 - Entry is a literal.
- 7 - Variable is a formal parameter.


8-11
Type

- | | | |
|---|---|---------------------|
| { | 1 | integer |
| | 2 | real |
| | 3 | complex |
| | 4 | double |
| | 5 | logical |
| | 8 | statement number |
| | 9 | common section name |


2. STATEMENT NUMBER - The first two words are the standard pointer/type. The next three words are the statement number, with leading zeros deleted, in stripped six-bit ASCII, filled to the right with blanks.




3. INTEGER OR REAL LITERALS - The first two words are the pointer and type. The next three words are the value in standard floating-point format (12-bit exponent, 24-bit signed 2's complement mantissa). Since the type of the literal must be preserved, there are two lists; hence use of 1 and 1.0 in the same program will cause one entry in each of the integer and real literal lists.




4. COMPLEX LITERALS - The first two words are standard. The next three are the real part in standard floating-point format. The next three are the imaginary part.



5. DOUBLE PRECISION LITERALS - The first two words are standard. The next six are the literal in FPP extended format (72-bit exponent, 60-bit mantissa).



6. HOLLERITH (quoted) LITERALS - The first two words are standard. The next N words are the characters of the literal in stripped six-bit ASCII, ending in a zero character.



7. DIMENSION INFORMATION BLOCK - If a variable is DIMENSIONED, the third word of its symbol table entry will point to its dimension information block (may be indirectly, see section 8 below). The first word of this block is the number of dimensions. The second word is the total size of the array in elements; thus the size in PDP-8 words may be 3 or 6 times

this number. The third word contains the "magic number" which is computed as follows:


$$MN = 1 + \sum_{i=1}^{n-1} \sum_{j=1}^i d_j$$

where d_j is the j^{th} dimension and n is the number of dimensions.


For a 3-dimensional variable this number becomes:

$$MN = 1 + d_1 + d_1 d_2$$


The magic number must be subtracted from any computed index, since indexing starts at one and not zero. The fourth word will (in PASS2) contain the displacement from #LIT of a literal which will contain either the magic number in un-normalized form (for dimensioned variables which are subroutine arguments) or the address of the variable minus the magic number (for local or COMMON dimensioned variables). This literal is necessary for calling subroutines where a subscripted variable is an argument. The next N words are the dimensions of the variable. If the variable is a formal parameter of the subroutine, it may have one or more dimensions which are also formal parameters. In this case, the magic number is zero, and the dimension(s) is a pointer to the symbol table entry for the variable(s) used as a dimension.



8. EQUIVALENCE INFORMATION BLOCK - If a variable is an EQUIVALENCE slave variable, the third word of its symbol table entry points to the equivalence information block. The first word of this block points to the dimension information (if any) of the variable. The second word points to the symbol table entry of the EQUIVALENCE master variable. The third word is the linearized subscript of the master variable from the EQUIVALENCE statement. The fourth word is the linearized subscript of the slave variable.



9. COMMON INFORMATION BLOCK - If a symbol is defined as the name of a COMMON section, the third word of its symbol table entry points to a list of common information blocks. The first word of each such block points to the next block. The second word is the number of entries in the list that follows. The rest of the block is a set of pointers to the symbol table entries of the variables in the COMMON section.



PASS1 OUTPUT

The output of PASS1 is a stream of polish with many special operators. Whenever an operand is to be output, the address of its symbol table entry is used. The following is a list of the output codes (in their mnemonic form, obtain numeric values from listing of PASS1) and the operation they are conveying to PASS2:

PUSH	The next word in the output file is an operand (symbol table pointer) to be put onto the stack.
ADD	Add the operands represented by the top two stack entries (actually this causes PASS2 to generate the RALF coding which will do the desired add).
SUB	Subtract top from next-to-top.
MUL	Multiply top two.
DIV	Divide top into next-to-top.
EXP	Raise next-to-top to power of top.
NOT	Logical .NOT. of top of stack.
NEG	Negate top of stack.
GE	Compare top two for greater than or equal to, this has TRUE value if the next-to-top is .GE. the top.
GT	Compare for greater than.
LE	Compare for less than or equal.
LT	Compare for less than.
AND	Logical AND of top two entries.
OR	Logical inclusive OR of top two.
EQ	Compare top two for equality.
NE	Compare top two for inequality.
XOR	Exclusive OR of top two.
EQV	EQUIVALENCE of top two.
PAUSOP	Use top of stack as PAUSE number.
DPUSH	The next two words are a symbol table pointer and a displacement; put them onto the stack (used for DATA statements).
BINRD1	Take the top of stack as the unit number and compile an unformatted READ-open.
FMTRD1	The top two stack elements are the unit and format, take them and compile a formatted READ-open.

RCLOSE	Compile a READ-close.
DARD1	Take the top two stack elements as a unit number and a block number and compile a direct access unformatted READ-open.
BINWRI	} Same as for the corresponding READ case, except substitute the word "WRITE".
FMTWRI	
WCLOSE	
DAWRI	
DEFFIL	Take the top four stack entries as the unit, number of records, record size, and index variable and compile a DEFINE FILE call.
ASFDEF	Set the PASS2 switch which says that the following statement is an arithmetic statement function.
ARGSOP	The next word is a count, call it n; take the previous n stack entries as subscripts (or arguments) and the N+1 st entry from the top as the array (or function) name; now compile this as an array reference (or function/subroutine call).
EOLCOD	The current statement is completed, reset stacks and do other housekeeping.
ERRCOD	The following word contains an error code, write it on the TTY together with the current line number, and put the error code and line number into the error list for possible PASS3.
RETOPR	Compile a subroutine RETURN.
REWOPR	Take the top of stack as a unit and compile a rewind.
STOROP	Compile a store of the top of stack into the next-to-top.
ENDOPR	Compile a RETURN if a function or subroutine or a CALL EXIT if a main program.
DEFLBL	The following word is a symbol table pointer to a statement number, compile this as the tag for the current RALF line.
DOFINI	The following word is a symbol table pointer for the DO-loop index, compile the corresponding DO-ending code.
ARTHIF	The following one, two, or three words are symbol table pointers to statement numbers for the less than zero, zero, and greater than zero conditions with the comparison to be made on the top of stack.
LIFBGN	The top of stack is taken as a logical expression PASS 2 should compile a jump-around-on-false; this implies that some statement is to follow.

DOBEGIN The top two stack entries represent the final value and increment of the DO-loop, process them in hopes of finding a matching DOFINI.

ENDFOP The top of stack is a unit, compile an END FILE.

STOPOP Compile a CALL EXIT.

ASNOPR The next word is the address of the symbol table entry for a statement number; compile an ASSIGN of this statement number to the variable represented by the top of stack.

BAKOPR Take the top of stack as the unit and compile a BACKSPACE.

FMTOPR The following word is a count N; the next N words after that are the image of the FORMAT statement.

GO2OPR The following word is the symbol table entry for the statement number which is to be executed next.

CGO2OP The following word is a count N; the next N words are symbol table pointers for the statement numbers of a computed GO TO list; use the value represented by the top of stack to compile a computed GO TO into this list.

AGO2OP Compile an assigned GO TO with the top of stack.

IOLMNT Take the top of stack as a list element for an I/O statement and compile read or write; PASS2 knows if it is a READ or WRITE by remembering previous FMTRD1, FMTWR1, etc.

DATELM The next word is a count N; the next N words are a data element.

DREPTC The next word is a repetition count for the set of DATELMs up until the next ENDELM.

ENDELM Signals the end of a data element group.

PRGSTK Tells PASS2 to purge the top stack entry.

DOSTOR Performs the same function as STOROP after checking the top two stack elements for legal DO-parameter type (integer or real).

PASS 1 SUBROUTINES

The following is a brief description of the function of each of the major PASS1 subroutines:

RDWR Compiles everything in a READ or WRITE statement starting at the first left parenthesis.

RESTCP	Restore character pointer and count for the statement buffer from the stack.
OUTWRD	Output a word (the AC on entering) to the PASS1 output file.
COMARP	Test for comma or right parenthesis; skip one instruction if a comma, two if a right parenthesis, and none if neither.
BACK1	Backup the statement buffer character pointer.
GETSS	Scans a variable reference, or subscripted variable reference with numeric subscripts and returns the linearized subscript.
MUL12	Perform a 12-bit unsigned integer multiply.
DOSTUF	Handles compilation of DO-loop setup.
TYPLST	Process a type declaration, DIMENSION, or COMMON statement; sets up type bits and/or dimension information.
LOOKUP	Perform a symbol table search for variables and Hollerith literals.
LUKUP2	Perform a symbol table search for integer, real, complex, and double precision literals or statement numbers.
EXPR	Analyze and process an arithmetic expression.
LETTER	Get next character from the statement buffer and skip if it is a letter, otherwise put the character back and don't skip.
CHECKC	The first word after the JMS is the negative of the ASCII character to test for; if this is the next character, skip.
GETCWB	Get the next character from the statement buffer preserving blanks.
SAVECP	Save the character pointer and count on the stack.
GETC	Get the next character ignoring blanks.
ERMSG	Output an error code to PASS1 output file.
POP	Pop the stack into the AC.
PUSH	Push the AC onto the stack.
LEXPR	Analyze and process an arithmetic expression, legal to the left of the equal sign in an assignment statement.
GET2C	Get the next two character into one word.

STMNUM	Scan off a statement number and do the symbol table search.
DIGIT	Same as letter, except checks for a digit.
NUMBER	Scans off an integer, real, or double precision literal.
GETNAM	Scan off a variable name.
ICHAR	Get the next character from the input file.

PASS2 OPERATION

The first part of PASS2 generates the storage for variables, arguments, arrays, literals and temporaries by processing the symbol table built by PASS1, which is kept in core. The next step is to generate the code for subroutine entry and exit including argument pickup and restore. After all such prolog code is generated, PASS20 is loaded into core, overlaying most of the prolog-generating functions. The main loop of the compiler is now entered. This consists simply of reading a PASS1 output code from the intermediate file and using this number as an index into a jump table. The sections of code entered in this way then perform the correct generation of RALF code.

Example:

The statement: $A=B+C*D$
 would produce the following PASS1 output:
 (assuming A,B,C,D are REAL)

- 1) PUSH
 →A (symbol table address of A)
- 2) PUSH
 →B
- 3) PUSH
 →C
- 4) PUSH
 →D
- 5) MUL
- 6) ADD
- 7) STOROP
- 8) EOLCOD

The corresponding operations performed by PASS2 are:

- 1) Make a 3-word entry on the stack corresponding to the variable A consisting of a pointer to the symbol table entry, a word containing the type, and one reserved word.
- 2) Repeat above for B.
- 3) Repeat above for C.
- 4) Repeat above for D.
- 5) The multiply operator is handled like any of the binary operators by the subroutine CODE. This routine is called with the address of the multiply skeleton table. The top two stack entries are taken as the operands, with their types used to index into the skeleton tables. (See description of binary operator skeleton tables below.) The correct skeleton for this combination is chosen based on the where-about of each of the operands (AC or memory) at the corresponding point in the code which is being compiled. There are three possible cases: Memory,AC; Memory,Memory; AC,Memory. In this example, both operands are in memory so the code generated would be:

FLDA C

FMUL D

The CODE subroutine then makes a new stack entry to replace the entries for C and D. This entry has a \emptyset in place of the symbol table pointer, signifying that the operand is in the AC. Other special case operand codes are:

\emptyset - AC (Already mentioned)

1 - 51 Temporaries

52 - 6 \emptyset Array reference, the subscript of which is in an index register (1-7).

61 - A variable, the address of which is in base location \emptyset .

62 - A variable, the address of which is in base location 3.

63-6777 - Symbol table entry (can be variable or literal).

7000 - Special temporary

- 6) The add operator is handled in the same way as for multiply, except that in this case the add skeleton table is used. When the correct row is found, the memory,AC case is chosen since the result of C*D is now in the AC. This skeleton simply generates:

FADD B

The new top of stack entry is a \emptyset , since the result is in the AC.

- 7) The store operation works in a similar manner using a special skeleton table to determine whether the value to be stored is

already in the AC and whether it must be converted from one type to another. In this case, no conversion need be performed and the code generated is:

FSTA A

- 8) The end of statement has been reached and any necessary bookkeeping is performed.

PASS2 SYMBOL TABLE

PASS2 modifies the symbol table entries corresponding to variables by replacing the first word of the entry with the first character of the name, this character being derived from the list in which the name is located.

PASS2 ERROR LIST

PASS2 creates a list (in field 1) of error codes and line numbers corresponding to the errors printed on the Teletype during PASS2. This list works downward starting just below the skeleton table area, working towards the symbol table area. PASS3 uses this list to write out extended error messages on the listing.

PASS2 SKELETON TABLES

All binary operators have associated with them a skeleton table having 24 entries arranged in 8 rows and 3 columns. The rows correspond to the following eight possibilities:

- 1) Both operands integer or real.
- 2) Both operands complex.
- 3) Both operands double precision.
- 4) First operand integer or real, second complex.
- 5) First operand integer or real, second double precision.
- 6) First operand complex, second integer or real.
- 7) First operand double precision, second integer or real.
- 8) Both operands logical.

The columns correspond to the following three possibilities:

- 1) First operand in memory, second in AC.
- 2) Both operands in memory.
- 3) First operand in the AC, second in memory.

Each entry of the skeleton tables is either zero (illegal operator-type combination) or points to a code skeleton (minus one). Code skeletons are composed of combinations of the following types of elements:

- 1) OPCODES - If an element has a non-negative value, it is taken as the address of a text string for the desired opcode. This works since all such text strings are stored below location 4000 (in field 0). In this case, the next word of the skeleton is taken as a designator for the address field, the possibilities are:
 - a. A non-negative value means the address field is a literal text string, with the value being the address of the string. (Same restriction as for opcode text strings.)
 - b. A zero indicates that this instruction should have no address field.
 - c. A minus one indicates that the address field is the operand defined by the three variables ARG1, TYPE1, and BASE1.
 - d. A minus two indicates that the address field is the operand defined by the three variables ARG2, TYPE2, and BASE2.
- 2) MODE CHANGE - An element value of minus one means generate a STARTF if currently in extended mode. A value of minus two means generate a STARTE if currently in single mode.
- 3) MACRO - Any other negative value is taken as the address (minus 3) of a sub-skeleton. This sub-skeleton may contain anything except another sub-skeleton reference. When the end of the sub-skeleton is encountered, the main skeleton is re-entered.
- 4) END-OF-SKELETON - A zero indicates the end of the skeleton.

PASS2 SUBROUTINES

The following is a list of the major PASS 2 subroutines together with a brief functional description.

ERMSG	Output a 2-character error code together with the line number on the Teletype; also put the code and line number into the error list for PASS3.
UCODE	Generate the code for unary operators, given the skeleton table address.
CODE	Generate code for binary operators, given the skeleton table address.
INWORD	Read a word from the PASS1 output file.
FATAL	Output a fatal error message and exit to OS/8.
ONUMBER	Output the AC as a 4-digit octal number.
SAVEAC	Generate an FSTA #TMP+XXXX if necessary.
GENCOD	Generate the code specified by the given code skeleton.
OPCOD	Output a TAB followed by the specified opcode field.
OPCODE	Same as OPCOD, except output a second TAB after the opcode field.
OADDR	Generate the address field specified by the argument.
GENSTF	Generate STARTF if in E mode.
GENSTE	Generate STARTE if in F mode.
OSNUM	Output a statement number preceded by a "#".
CRLF	Output a carriage return/line feed.
OTAB	Output a TAB.
OUTSYM	Output a text string.
GARG	Pop the top entry of the stack into ARG1, TYPE1, and BASE1.
GARGS	Pop the top two stack entries into ARG1, TYPE1, BASE1 and ARG2, TYPE2, BASE2.
OUTNAM	Output a variable name.
OLABEL	Output a generated label.
GETSS	Find the address of the dimension information block given the symbol table address.
SKPIRL	Skip if integer, real, or logical.
GENCAL	Generate the code for a subroutine call from the information contained on the stack.
MUL12	Do a 12-bit unsigned multiply.

OINS	Output a literal opcode and address field.
OCHAR	Output a character
NUMBRO	Output a 5-digit octal number.

PASS3 OPERATION

PASS3 first initializes the listing header line with the version number, date, and page number. It then processes lines, much like PASS1, handling continuations and comments and outputs their image to the listing file together with the line number. A constant check is made on the error message list for line numbers that correspond to the current line number. When such a correspondence occurs, the error code is used to find the associated detailed error message, which is then printed out.

CHAPTER 2

THE RALF ASSEMBLER

RALF and FLAP are essentially the same program, with differences controlled by the conditional assembly parameter RALF, which must be non-zero to assemble RALF, or zero to assemble FLAP. The source may be assembled by either PAL8 or FLAP; although FLAP flags one error (a US on a FIELD statement), this may safely be ignored. The remainder of this chapter applies to RALF only. The following definitions are prerequisite to discussion of the operation of this assembler.

MODULE	The relocatable binary output of an assembly. A module is physically an OS/8 file or sub-file in a library, and is made up of an external symbol dictionary and related text. Logically, it consists of one or more program sections and COMMON sections.
LIBRARY	An OS/8 file on a directory device containing a catalog and one or more modules as sub-files. Used solely by the loader, as a source of modules with which to satisfy unresolved symbols in a program being loaded.
CATALOG	A list of entry points defined in modules contained in a library, with an indication of the locations of the modules which define them.
EXTERNAL SYMBOL DICTIONARY	A list of the global symbols defined in and/or used by a module. Usually called ESD table.
TEXT	That part of the assembler's binary output which contains the binary data to be loaded into memory, along with sufficient information for the loader to associate the output with specific memory locations through references to the ESD table.
SECTION	A unit of binary data output by the assembler as part of a module to be loaded into a contiguous area of memory. COMMON sections are a special case in that they may be defined with the same name in each of many modules. In this case, all the definitions are combined to create a single section in memory whose size is that of the largest COMMON section with the given name. Program sections, the only other type of section, must have unique names. Sections are listed in the ESD table by name, type and size.
ENTRY POINT	An address within a section which is named and defined to be global, so that it may be used for the resolution of external references in other sections. Entry points are listed in the ESD table by name, type and address within the section in which they occur.

EXTERNAL
SYMBOL

A symbol which is specified at assembly time to be defined in another module as an entry point. External symbols are listed in the ESD table by name and type. A complete program must include entry point names equivalent to every external symbol defined in every module in the program. There need not, however, be an external symbol for every entry point, nor is there any limit on the number of modules which may contain external symbols referencing one entry point. From a functional viewpoint, entry points correspond to tags within a program and external symbols correspond to references to those tags. Every section is considered to have an entry point at location zero of the section. The name of this entry point is the section name.

When RALF is called from the monitor, execution begins at the tag BEGIN. Unless entry is via CHAIN, the OS/8 command decoder is called to obtain input and output file designations. If entry is by way of CHAIN, it is assumed that the command decoder area has already been set up by the caller. In either case, it is always assumed that the USR is already in core. A check is made to determine that the first output file is a directory device file and, if no first output file was specified, the default file SYS:FORTRN.RL is set up.

Default output file extensions are defined if none were specified to the command decoder, using .RL for the first output file and .LS for the second output file. The first output file is then opened, and the handler for the first input file is FETChed. If /L or /G was specified, the loader is looked up on SYS so that chaining will be possible. The symbol table, which is loader above 12000 in order to preserve the USR, is now moved down to 10000. Finally, the system date word is converted to character form and stored in the title buffer. This completes the initialization procedure, and control is passed to NEWLIN to collect the first line in the buffer.

At NEXTST, tests are made to determine whether the line just assembled needs to be listed, and whether there are any remaining significant characters in the line which have not been assembled. If a semicolon

terminated the statement, the character pointers are bumped to skip over it, and control passes to ASMBL to process the next statement on the line. If the assembler is currently in a REPEAT line and the count is not exhausted, the current line is re-assembled. Otherwise, a new line is obtained in the line buffer by collecting input characters until a carriage return is found. If the line is longer than 128 characters, all characters after the 128th are ignored and the LT message is printed. The line length is calculated and saved.

At ASMBL, ASMOF is tested to determine whether the assembly is currently inside a conditional. If so, the line is scanned for angle brackets but not assembled. If not, and the first character is not a slash, leading blanks are thrown away and control passes to LUNAME. If there is a name, it is collected. If it is followed by a comma, the symbol is looked up in the user symbol table. If the symbol is undefined, it is defined as a label. If it was already defined, the current location counter is compared with it to check for a possible MD error. Control then returns to ASMBL.

If the symbol found by LUNAME was followed by an equal sign, it is looked up and defined according to the expression to the right of the equal sign. If it was followed by a space, either of the characters ' or #, or the character % and then a space, it is looked up in the op-code table. If it is found, control passes to the appropriate op-code handler. Otherwise, control is dispatched to GETEXP which restores the character pointers saved by LUNAME, processes the rest of the line as a single-word expression, and returns to NEXTST for the next statement.

Expressions are processed on a strict left-to-right basis by the routine EXPR. A symbol is looked up, and its value is stored in WORD1 and WORD2. It is then combined with the accumulated expressions in EXPVAL according to the operator in LASTOP. A new operator (if any) is then located, and the loop begins again. When no operator is found after some symbol, the expression is considered complete and control returns to the calling routine. Undefined symbols appearing in an expression cause output of a US message, and the value zero is used in their place. COMMON and section names in the symbol table have special values (namely their lengths), but they always refer to the starting location of the sections they define, and their values are taken to be zero of the section so named. If GETNAM is not able to find a symbol in the expression, three possibilities are checked before flagging the expression as invalid:

1. It may be a number, rather than a symbol.
2. It may be one of the characters period (representing the current value of the location counter) or double quote (representing the binary value of the next ASCII character).
3. The last operator may have been a plus sign in an indexed FPP instruction.

At the end of expression evaluation, the console keyboard flag is checked to ensure that the user has not typed CTRL/C to stop the assembly.

There are six expression operator routines, one each for the operations add, subtract, AND, OR, multiply and divide. Except for add and subtract, these routines must operate on absolute addresses because the loader does not have facilities for non-additive resolution of address constants.

The symbol table is the sole occupant of field 1, except for the OS/8 field 1 resident. The symbol table is loaded at location 12000 to prevent an unnecessary swap of the USR, but moved down, to start at location 10000, during initialization. Subsequent calls to the USR do require a swap. The symbol table is a set of linked lists, or, more properly, two sets; one for user-defined symbols and one for op-codes and pseudo-ops. Each set contains a list corresponding to every letter of the alphabet, and each list consists of the symbols which start with that same letter. Every time a symbol is encountered in the source, the list corresponding to its first letter is searched until a match is found, or until the end of the list or a symbol of higher alphabetical order is found. In the latter cases, the new symbol is inserted into the user symbol table by changing the list pointers so that the new symbol appears in the list in correct alphabetical order. The pre-defined symbol table is never changed, because the user is not permitted to define op-codes or pseudo-ops.

A RALF output file of relocatable binary data consists of two parts; the ESD table and the text. The ESD table contains all information required by LIBRA or the loader, and is generated between the first and second passes of assembly. It serves as a partial symbol table for the loader (the full symbol table is built up from the ESD tables of all the modules in a program) and provides the name, attributes, and value of every global symbol used by any module, as well as an ESD code by which the symbol may be referred to within the text. Every entry in the ESD table is six words long. The first three words are the symbol itself, packed in stripped ASCII, with two characters per word. The next word contains type information in the following format:

A VALUE OF	INDICATES
0	Last entry in the ESD table.
1	The symbol is defined as external to this module. The value of the symbol must be resolved by a symbol of the same name appearing in the ESD table of another module. The ESD code which follows the type code is the code by which references to this symbol will be identified in the text.
2	The symbol is defined as an entry point in this module. It is therefore suitable for the resolution of external references in other modules. The ESD code which follows the type word identifies the program section in which this entry point appears, and the value of the symbol is relative to that section.
3	The symbol is defined as a COMMON section whose size is at least as large as specified by the value of the symbol. If several modules contain ESD entries referring to COMMON sections with the same name, a single COMMON block having the size of the largest symbol is allocated for all of them. A name consisting of blanks is treated in the same manner as any other name.
4	The symbol is defined as a section of location independent (that is, fully word-relocatable) code of a size equal to the value of the symbol. The ESD code for this section allows text from the module to be included in this section, and relocated with respect to it.
5-17	Undefined

The text portion of a relocatable binary file consists of the binary data to be loaded into memory, along with information directing the loader on how to modify that data to correct the addresses for program relocation. The first word of text is a control word, which is made up of a 4-bit type code and an 8-bit indicator. Following the control word, and depending on the type code, are a number of data words to be loaded as directed by the type code and the indicator. The control word type codes are:

CODE	FUNCTION
0	End of text, if the indicator is zero, or no operation otherwise.

- 1 Copy the number of words given by the indicator from text directly into memory without modification.
- 2 Re-origin to the section identified by the indicator, with a relative location defined by bits 9-23 of the following doubleword. Thus, the next two words define a new origin for the following text, in the program section identified by the indicator.
- 3 Relocate the following doubleword bits 9-23 by the value of the symbol whose ESD code is identified by the indicator. The following doubleword is usually a two-word FPP instruction, the low-order 15 bits of which are to be relocated by the value of the symbol identified by the indicator.

WRITING PDP-8 CODE UNDER OS/8 FORTRAN IV

RALF contains the normal set of PDP-8 instructions (TAD, DCA, CDF, KSF, etc.), however RALF does not allow literals, the PAGE pseudo-op, or the use of I to specify indirect addressing. PDP-8 code generated by RALF is not relocatable; therefore, operations such as the following are illegal:

```

      EXTERN SWAP      /Illegal
      TAD (SWAP       /Under
      CDF SWAP        /RALF

```

The character % appended to the end of a memory reference instruction indicates indirect addressing, and the character Z indicates a page 0 reference:

CURRENT PAGE		PAGE ZERO	
DIRECT	INDIRECT	DIRECT	INDIRECT
TAD A	TAD% A	TADZ A	TADZ% A
DCA B	DCA% B	DCAZ B	DCAZ% B

Spaces are not allowed between memory reference instructions and either the Z or the % characters. The Z must precede the % when both are used. I.e., do not write "DCA%Z".

Three pseudo-ops have been added to RALF: SECT8, COMMZ, and FIELD1. All three define sections of code and are handled in the same manner

as SECT; however, these new sections have special meaning for the loader. The address pseudo-op (ADDR) which generates a two word relocatable 15 bit address (i.e., JA TAG without use of JA) might prove useful in 8-mode routines. The following example demonstrates a way in which an 8-mode routine in one RALF module calls an 8-mode routine in another module:

```

        EXTERN SUB
        .
        .
        RIF          /Set DF to current
        TAD ACDF     /IF for return
        DCA .+1
        0            /CDF X
        TAD KSUB     /Make a CIF from
        RTL CLL      /Field bits
        RAL
        TAD ACIF
        DCA .+1
        0            /CIF to field
                    /Containing SUB
        JMS% KSUB+1

KSUB,   ADDR SUB    /Psuedo-op to
                    /Generate 15 bit
                    /ADDR of subroutine
                    /SUB

ACDF,   CDF
ACIF,   CIF

```

In general the address pseudo-op can be used to supply an 8-mode section with an argument or pointer external to the section.

FPP and 8-mode code may be intermixed in any RALF section. PDP-8 mode routines must be called in FPP mode by either:

```

        TRAP3 SUB
or      TRAP4 SUB

```

A TRAP3 SUB causes FRTS to generate a JMP SUB with interrupts on and the FPP hardware (if any) halted. TRAP4 generates a JMS SUB under the same conditions. The return from TRAP4 is:

```

        CDF CIF 0
        JMP% SUB

```

The return from TRAP3 is:

```

        CDF CIF 0
        JMP% RETURN+1

```

```

        EXTERN #RETRN
RETURN, ADDR #RETRN

```

Communication between FPP and 8-mode routines is best done at the FPP level because of greater flexibility in both addressing and relocation in FPP mode. The following routine demonstrates how to pass an argument to, and retrieve an argument from, an 8-mode routine:

```

        EXTERN SUB
        EXTERN SUBIN
        EXTERN SUBOUT
        .
        .
        .
        FLDA X          /Arg for SUB
        FSTA SUBIN
        TRAP4 SUB      /Call SUB
        FLDA SUBOUT    /Get result
        FSTA Y

```

If the 8-mode routine SUB were in the same module as the FPP routine, the externs would not be necessary. In practice it is common for FPP and 8-mode routines that communicate with one another to be in the same section. A number of techniques can be used to pass arguments. For example, an FPP routine could move the index registers to an 8-mode section and pass single precision arguments via ATX.

Because 8-mode routines are commonly used in conjunction with FPP code (generated by the compiler), the 8-mode programmer should be familiar with OS/8 FORTRAN IV subroutine calling conventions. The general code for a subroutine call is a JSR, followed by a JA around a list of arguments, followed by a list of pointers to the arguments. The FPP code for the statement:

```

        CALL SUB (X,Y,Z)

```

would be

```

        EXTERN SUB
        JSR    SUB
        JA     BYARG
        JA     X

```

```

        JA      Y
        JA      Z
BYARG,  .
        .
        .
        .

```

The general format of every subroutine obeys the following scheme:

```

        SECT  SUB
        JA    #ST      /Jump to start of
                       /Routine
        TEXT  +SUB+    /Needed for
                       /Trace back
RTN,      SETX  XSUB   /Reset SUB's index
        SETB  BSUB   /And base page
BSUB,     FNOP          /Start of base page
        JA    .
        .
        .
        ORG   BSUB+30  /Restart for SUB
        FNOP:JA RTN
GOBAK,    FNOP:JA .    /Return to
                       /Calling program

```

Location 00000 of the calling routine's base page points to the list of arguments, if any, and may be used by the called subroutine provided that it is not modified. Location 0003 of the calling routine's base page is free for use by the called subroutine.

Location 0030 of the calling routine's base page contains the address where execution is to continue upon exit from the subroutine, so that a subroutine should not return from a JSR call via location 0 of the calling routine:

CORRECT	INCORRECT
FLDA 30	FLDA 0
JAC	JAC

The "non-standard" return allows the calling routine to reset its own index registers and base page before continuing in-line execution.

General initialization code for a subroutine would be:

```

        SECT          SUB
        JA            #ST
        .
        .
        .
        BASE          0

```



```

#ST, STARTD      /So only 2 words
                  /Will be picked up
FLDA      30     /Get return JA
FSTA      GOBAK  /Save it
FLDA      0      /Get pointer to list
SETX      XSUB   /Set SUB's XR
SETB      BSUB   /Set SUB's Base
BASE      BSUB
INDEX     XSUB
FSTA      BSUBX  /Store pointer
                  /Somewhere on Base
.
.
.
STARTF     /Set F mode before
JA      GOBAK  /Return

```

The above code can be optimized for routines that do not require full generality. The JA #ST around the base page code is a convenience which may be omitted. The three words of text are necessary only for error traceback and may also be omitted. If the subroutine is not going to call any general subroutines, the SETX and SETB instructions at location RTN and the JA RTN at location 0030 are not necessary. If the subroutine does not require a base page, the SETB instruction is not necessary in subroutine initialization; similar remarks apply to index registers. If neither base page nor index registers are modified by the subroutine, the return sequence:

```

FLDA 0
JAC

```

is also legal. In a subroutine call, the JA around the list of arguments is unnecessary when there are no arguments. A RALF listing of a FORTRAN source will provide a good reference of general FPP coding conventions.

In order to generate good 8-mode code, one must be aware of the manner in which the loader links and relocates RALF code. The loader handles three 8-mode section types: COMMZ, FIELD1, and SECT8. All three types of section are forced to begin and end on page boundaries and to be a part of level MAIN; 8-mode sections never reside in overlays. COMMZ and FIELD1 sections are forced to reside in field 1; SECT

sections may be in any field. The first COMMZ section encountered is forced to begin at location 10000, thus enabling a page 0 in field 1. COMMZ sections of the same name are handled like COMMON sections of the same name (i.e., they are combined into one common section). This feature allows 8-mode code in different modules to share page 0, provided that the modules do not destroy each other's page 0 allocations. Suppose two modules were to share page 0, with the first using location 0-17 and the second using locations 20-37:

```

                                /Module A
                                COMMZ SHARE
P1,      1
P2,      2
KSUBA1,  SUBA1
KSUBA2,  SUBA2
.
.
.
LASTA,   -1                      /Should not go over
                                /20 locations
FIELD1   A

                                TADZ P1
                                JMSZ% KSUBA1
.
.
.
                                /Module B
                                COMMZ SHARE
                                ORG .+20          /ORG past module A's
                                                /Page 0
P3,      3
P4,      4
KSUBB,   SUBB
.
.
.
LASTB    -2
FIELD1   B
                                TADZ P3
.
.
.

```

The two COMMZ sections will be put on top of one another, however, because of the ORG .+20 in module B, they will effectively reside back to back. When the image is loaded, the COMMZ sections will look as follows:

LOC	CONTENTS	
1 0000	1	
0001	2	
2	SUBA1	
3	SUBA2	
.		
.		
1 0017	-1	/LASTA
1 0020	3	
21	4	
22	SUBB	
.		
.		
37	-2	/LASTB

If module A is to reference module B's page 0, the procedure is:

```
P3=20
TADZ P3
```

Alternately, a duplicate of the source code for COMMZ SHARE may be included in module B. Modules that are using the same COMMZ section must be aware of how it is divided up. Although COMMZ SHARE takes only 40 locations, the loader allocates a full 200 locations to it. All 8-mode section core allocations are always rounded up so that they terminate on a page boundary. If COMMZ sections of different names exist, they are accepted by the loader and inserted into field 1, but only one COMMZ is the real page 0. In general, it is unwise to have more than 1 COMMZ section name.

FIELD1 sections are identical to COMMZ sections in most respects. Memory allocation for FIELD1 sections is assigned after COMMZ sections, however, and FIELD1 sections are combined with FORTRAN COMMON sections of the same name as well as other FIELD1 sections of the same name. The first difference ensures that COMMZ will be allocated page 0 storage even in the presence of FIELD1 sections. The second allows PDP-8 code to be loaded into COMMON, making it possible to load initialization code into data buffers. Two FIELD1 sections with the same name may be combined in the same manner as two COMMZ sections.

The primary purpose of COMMZ is to provide a PDP-8 page 0; the primary purpose of FIELD1 is to ensure that 8-mode code will be loaded into field 1 and that generating CIF CDF instructions in-line is not necessary. SECT8 sections may not be combined in the manner of a COMMON and are not ensured of being placed into field 1.

An 8-mode section does not have to be less than a page in length; however, the programmer should be aware that a SECT8 section which exceeds one page may be loaded across a field boundary and could thereby produce disastrous results at execution time. For this reason, it is generally unwise to cross pages in SECT8 code. This situation will never occur on an 8K configuration. If the total amount of COMMZ and FIELD1 code exceeds 4K, the loader generates an OVER CORE message. The loader generates an MS error for any of the following:

1. A COMMZ section name is identical to some entry point or some non-COMMZ section name.
2. A FIELD1 section name is identical to some entry point or a SECT, SECT8 or COMMZ section name.
3. A SECT8 section name is identical to an entry point or some other section name.

COMMZ sections, like FORTRAN COMMONS, are never entered in the library catalog.

For users who intend to write 8-mode code that will execute in conjunction with certain 8-mode library routines, the layout of PDP-8 FIELD1 #PAGE 0 is:

LOCATION	USE
0-1	Temps for any non-interrupt time routine.
2-13	User locations.
14-157	System locations.
160-177	User locations.

1. Do not define any COMMZ sections other than the system COMMZ which is #PAGE0.

2. If the system page 0 is desired, it will be pulled in from the library if EXTERN #DISP appears in the code.

3. Do not use any part of page 0 reserved for the system.

Special purpose PDP-8 mode subroutines may be written to perform idle jobs (refreshing a scope, checking sense lines) or to handle specific interrupts not serviced by FRTS.

The run-time system enters idle loops while waiting for the FPP to complete a task or for an I/O job to complete. It is possible to effect a JMS to a user routine during the idle loop.

RTS contains a set of instructions such as:

```
#IDLE, JMP  .+4
          0
          CDF CIF
          JMS I  .-2
```

This sequence of instructions must be revised if an IDLE routine is to be called.

The location #IDLE must be changed to a SKP (7410). #IDLE+1 must be set to the address of the routine to be called. #IDLE+2 must be set to a CDF CIF to the field of the routine. This setup can be done in a routine that is called at the beginning of MAIN. For example:

```
CALL SETIDL
```

where SETIDL is a routine such as:

```
SECT8 SETIDL      /Must be an 8-mode section
JA #RET
TEXT +SETIDL+    /Traceback information
SXR, SETX XR
SETB BP
BP, 0.0
XR, 0.0
.
.
.
ORG 10*3+BP
```

```

        FNOP                /For trace back
        JA SXR
        .
RET,    0                    /Return address
        .
        .
#RET,   STARTD              /Set up
        FLDA 10*3          /Return address
        FSTA RET
        SETB BP            /Just for traceback
        TRAP4 SET8        /Go to the 8 mode
                           /Routine set 8

        STARTF
SET8,   JA RET              /Return to main
        0
        TAD IDLAD         /Field of idle
        CLL RTL
        RAL                /Move to
                           /Bits 6-8
        TAD SCDF          /CDF to #IDLE
        DCA .+3
        TAD IDLAD+1      /Address of #IDLE
        DCA IDPTR
        0                  /CDF goes here
        TAD S7410        /SKP
        DCA% IDPTR       /Store at #IDLE
        TAD JOB+1        /Address of IDLE top routine
        ISZ IDPTR
        DCA IDPTR        /Store a #IDLE+1
        TAD JOB          /Field of routine
        CLL RTL
        RAL                /Position
        TAD SFIELD
        ISZ IDPTR
        DCA% IDPTR       /Store at #IDLE+2
        CDF CIF          /Set to field 0
        JMP% SET8        /Return to instruction
                           /Following "TRAP4 SET8"

IDLAD,  EXTERN #IDLE
JOB,    ADDR #IDLE        /15 bit address of IDLE
        ADDR DOIT        /15 bit address of IDLE
                           /Routine "DOIT"

SCDF,   6201              /CDF
SFIEL,  6203              /CDF CIF
IDPTR,  0
S7410,  7410              /Skip

                           /The following routine performs the
                           /IDLE task
                           /Executed during IDLE loops

DOIT,   0
        .
        .
        .                    /Perform task
        .
        CDF CIF 0        /Back to field 0
        JMP% DOIT        /And back

```

If the subroutine is checking for an illegal argument, an argument error message with traceback can be included in the subroutine by adding two lines somewhere on the base page:

```

                EXTERN #ARGER
    EXAMER, TRAP4 #ARGER

```

When the error is detected in the program, effect a jump to the TRAP4 instruction. For example,

```

    FLDA%   EXTMP1
    JEQ     EXAMER           /A value of 0 is illegal

```

or

```

    FLDA    EXTMP1
    FNEG
    FADD    EXTMP2
    JLT     EXAMER           /The value in EXTMP1 must be
                             /greater than that in EXTMP2

```

Some points to note in the above example

1. Using a # as the first character in the name of the start of the program assumes that the name is not called from the FORTRAN level. This is because # is an illegal FORTRAN keyboard character.
2. If index registers 3-5 are not used by the subroutine, the space from XR3 to the ORG statement can be used for temporary storage, if needed.
3. The arguments passed from the FORTRAN level do not have to be picked up all at once at the start of the calculation (3-word) portion of the program. They can be picked up as required during the program, can be saved in temporary space, or accessed indirectly each time required, as best suits the subroutine.

If a call to this routine such as Z=EXAMPL(A,B,C,D) were encountered by the compiler, it would generate the following call to the routine:

```

    JSR EXAMPL           /go to the routine
    JA  .+10             /jump around arguments
    JA  A                /pointer to 1st argument
    JA  B                /pointer to 2nd argument
    JA  C                /pointer to 3rd argument
    JA  D                /pointer to 4th argument

```

The AMOD routine is listed below to illustrate an application of the formal calling sequence. It also includes an error condition check and picks up two arguments. When called from FORTRAN, the code is AMOD(X,Y).

```

/
//
//
/      A M O D
/      - - - -
/
/SUBROUTINE      AMOD(X,Y)
      SECT      AMOD      /SECTION NAME(REAL NUMBERS)
      ENTRY    MOD      /ENTRY POINT NAME(INTEGERS)
      JA      #AMOD      /JUMP TO START OF ROUTINE
      TEXT    +AMOD +    /FOR ERROR TRACE BACK
AMODXR, SEIX    XRAMOD    /SET INDEX REGISTERS
      SEIB    BPAMOD      /ASSIGN BASE PAGE
BPAMOD, F 0.0   /BASE PAGE
XRAMOD, F 0.0   /INDEX REGS.
AMODX,  F 0.0   /TEMP STORAGE
      ORG     10*3+BPAMOD /RETURN SEQUENCE
      FNOP
      JA      AMODXR
      0
AMDRIN, JA      .        /EXIT
      EXTERN  #ARGER
AMODER, TRAP4  #ARGER    /PRINT AN ERROR MESSAGE
      FCLA
      JA      AMDRIN      /EXIT WITH FAC=0
      BASE    0          /STAY ON CALLER'S BASE PG
/LONG ENOUGH TO GET RETURN ADDRESS
MOD,          /START OF INTEGER ROUTINE SAME AS
#AMOD, STARTD /START OF REAL NUM. ROUTINE
      FLDA    10*3      /GET RETURN JUMP
      FSTA    AMDRIN    /SAVE IN THIS PROGRAM
      FLDA    0         /GET POINTER TO PASSED ARG
      SEIX    XRAMOD    /ASSIGN MOD'S INDEX REGS
      SEIB    BPAMOD    /AND ITS BASE PAGE
      BASE    BPAMOD
      LDX     1,1
      FSTA    BPAMOD
      FLDAZ   BPAMOD,1  /ADDR OF X
      FSTA    AMODX
      FLDAZ   BPAMOD,1+ /ADDR OF Y
      FSTA    BPAMOD
      STARTF
      FLDAZ   BPAMOD    /GET Y
      JEQ     AMODER    /Y=0 IS ERROR
      JGT     .+3
      FNEG
      /ABS VALUE
      FSTA    BPAMOD
      FLDAZ   AMODX     /GET X
      JGT     .+5
      FNEG
      /ABS VALUE
      LDX     0,1      /NOTE SIGN
      FSTA    AMODX    /SAV IN A TEMPORARY
      FDIV    BPAMOD    /DIVIDE BY Y
      JAL     AMODER    /TOO BIG.
      ALN     0        /FIX IT UP NOW.
      FNORM
      FMUL    BPAMOD    /MULITPLY IT.
      FNEG
      /NEGATE IT.
      FADD    AMODX     /AND ADD IN X.
      JXN    AM,1      /CHECK SIGN
      FNEG
AM, JA      AMDRIN    /DONE

```


RTS has its own interrupt skip chain in which all on-line device flags are checked and serviced. This chain may be extended to handle special interrupts. The external tag #INT marks the first of three locations on RTS which have to be modified to effect a JMS to the user's special interrupt handler. The three locations must be set up in exactly the same manner as that used to set up #IDLE, #IDLE1, #IDLE2 as described above. All the same conventions hold. Refer also to the library subroutines ONQI and ONQB.

Three pseudo-ops have been added to RALF to help the loader determine core allocation. Each is a more definitive case of the SECT pseudo-op and defines a chunk of code, thereby providing more control for the user. They are:

- SECT8 - section starts at a page boundary
- FIELD1 - section starts at a page boundary and is in field 1
- COMMZ - section starts at page 0 of field 1

If there is more than one SECT8 section in a module, those sections are not necessarily loaded in contiguous core. The loader considers core to be in two chunks - one block in field 0, and all of field 1 and above.

If there is more than one COMMZ pseudo-op in a module, they are stacked one behind the other, but there is no way of specifying which one starts at absolute location 0 of field 1. COMMZ sections are allocated by the loader before FIELD1 sections.

Modules can share a COMMZ section in the same way that FORTRAN COMMON sections can be shared. FIELD1 sections can also be shared by using the same FIELD1 section name in each module.

The first occurrence of a section name defines that section. For example,

```

SECT8 PARTA
:
SECT8 PARTB
:
SECT8 PARTA

```

The second mention of PARTA in the same module continues the source where the first mention of PARTA ended at execution time. (There is a location counter for each section.)

To save core, a RALF FIELD1 section and FORTRAN COMMON section of the same name are mapped on top of each other, being allocated the length of the longer and the same absolute address by the loader. This feature is useful for initialization (once-only) code, which can later be overlaid by a data area. Thus, the occurrence of FIELD1 AREAL in the RALF module and COMMON AREAL in the FORTRAN program causes AREAL to start the same location (in field 1) and have a length of at least 200 locations (depending on the length of the RALF FIELD1 section or of the COMMON section in the FORTRAN).

If the subroutine is longer than one page and values are to be passed across page boundaries, the address pseudo-op, ADDR, is required.

The format is:

```
AVAR1, ADDR VAR1
```

This generates a two-word reference to the proper location on another page, here VAR1. For example, to pass a value to VAR1, possible code is:

```

00124 1244      TAD  VAR2          /Value on this page
00125 3757      DCA% AVAR1+1     /Pass through 12-bit
                                /location
00156 0000 AVAR1,ADDR VAR1      /Field and
00157 0322                                /location of VAR1

```

Any reference to an absolute address can be effected by the ADDR pseudo-op.

If it is doubtful that the effective address is in the current data field, it is necessary to create a CDF instruction to the proper field. In the above example, suitable code to add to specify the data field is:

```

TAD AVAR1           /Get field bits
RTL                /Rotate to bits 6-8
RAL
TAD (6201          /Add a CDF
DCA .+1           /Deposit in line
0                 /Execute CDFn

```

If the subroutine includes an off-page reference to another RALF module (e.g., in FORLIB), it can be addressed by using an EXTERN with an ADDR pseudo-op. For example, in the display program, a reference to the non-interrupt task subroutine ONQB is coded as

```

                EXTERN    ONQB
ONQBX,         ADDR     ONQB

```

and is called by

```

                JMS%      ONQBX+1

```

The next instruction in the program is ADDR DISPLY so that DISPLY will be added to the background list. Execution from ONQB returns after the ADDR pseudo-op.

It may be desirable to salvage the first (field) word allocated by ADDR pseudo-ops. If the address requires only twelve bits for proper execution, code such as

```

                TMP,      TMP,ADDR X
                ARG,ADDR X      or  ARG= .-1

```

permits TMP to be used for temporary storage because ARG+1 in the left hand example or just ARG in the right hand example defines the 12-bit address.

RALF does not recognize LINC instruction or PDP-8 laboratory device instructions. Such instructions can be included in the subroutine by defining them by equate statements in the program.

For example, adding the statements:

```
PDP = 2
LINC = 6141
DIS = 140
```

takes care of all instructions for coding the PDP-12 display subroutine.

When writing a routine that is going to be longer than a page, it can be useful to have a non-fixed origin in order not to waste core and to facilitate modification of the code. A statement such as

```
IFPOS .-SECNAM&177-K<ORG .-SECNAM&7600+200+SECNAM>
```

will start a new page only if the value [current location less section name] is greater than some K (start of section has a relative value of 0) where $K < 177$ and is the relative location on the current page before which a new page should be started. The ORG statement includes an AND mask of 7600 to preserve the current page. When added to 200 for the next page and the section name, the new origin is set.

When calculating directly in a module, the following rules apply to relative and absolute values.

```
relative - relative = absolute
absolute + relative = relative
OR (!), AND (&) and ADD (+) of relative symbols
generate the RALF error message RE.
```

When passing arguments (single precision) from FPP code to PDP code, using the index registers is very efficient. For example,

```

:
FLDA%  ARG1          /Get argument in FPP mode
SETX   MODE8        /Change index registers so XR0 is
:                               /At MODE8
ATX    MODE8        /Save argument
:
TRAP4  SUB8         /Go to PDP-8 routine
:
SUB8,  0             /PDP-8 routine
:
TAD    MODE8        /Get argument
:
MODE8, 0             /Index registers set here
:
```

CHAPTER 3

THE FORTRAN IV LOADER

The FORTRAN IV loader accepts a set of (up to 128) RALF modules as input, and links the modules, along with any necessary library components, to form a loader image file that may be read into memory and executed by the run-time system. The main task accomplished by the loader is program relocation, achieved by replacing the relative starting address of every section with an absolute core address. Absolute addresses are also assigned to all entry points, all relocatable binary text, and the externs.

The loader executes in three passes. Pass 0 begins by determining how much memory is available on the running hardware configuration, and then constructs tables from the OS/8 command decoder input for use by pass 1 and pass 2.

Pass 1 reads the relocatable binary input and creates the loader symbol table. The length of each input module is computed and stored, along with the relative values of entry points defined within the input modules. When an undefined symbol is encountered, pass 1 searches the catalog of the FORTRAN IV library specified to pass 0, or FORLIB.RL if no other library was explicitly specified, and loads the library routine corresponding to the undefined symbol.

Pass 1 also allocates absolute core addresses to all modules and, through them, to all symbols. Pass 1 execution concludes by computing the lengths of all overlay levels defined for the current FORTRAN IV job. Trap vectors are also set up at this time, and the tables required for pass 2 loading are initialized.

Pass 2 concludes loader execution by creating a loader image file from the relocated binary input and symbol values processed by pass 1.

LOADER PASS 0 (FILE COLLECTION)

00000	OS/8 Command Decoder	FIELD 0
02000	Loader Pass 1 and Pass 2	
04600	Core measuring routine and scratch area to save 00000-02000 during CD calls	
06600	Unused	
07600	OS/8 Field 0 resident	
10000	OS/8 User Service Routine	FIELD 1
12000	Symbol table, loader map titles	
12400		
13200	Pass 0 code	
14000	Pass 1 initialization	
16000	Module count and module tables	
17000	Library catalog header read into this block	
17600	OS/8 Field 1 resident	

Pass 2 also produces the loader symbol map, if requested, and chains to the run-time system if /G was specified.

Pass 0 contains very few subroutines. The routine CORDSW checks for the presence of /U, /C or /O option specifications, as supplied to the command decoder, and processes these options if necessary. A routine called UPDMOD is called when input to each overlay has been concluded, to update the module counts in the module count table.

LOADER PASS 1 (SYMBOL RESOLUTION)

00000	Pass 1 and Pass 2 utility routines	FIELD 0
01400	Symbol map printer	
02000	Pass 2	
03200	Pass 1 symbol collection	
04000	Inter-pass code allocates storage, builds and writes Loader Image Header Block.	
04600	Library catalog loads here in 8K. Unused in 12K or more.	
07200	Input device handlers	
07600	OS/8 Field 0 resident	
10000	ESD table	FIELD 1
11400		
12000	Symbol table	
15400	Overlay length table	
16000	Module count and module tables (MCTTBL, MODTBL)	
17200	Loader header	
17400	ESD reference page	
17600	OS/8 Field 1 resident	
20000	Library catalog loads here in 12K or more.	FIELD 2
25000	OS/8 BATCH processor if 12K or more and BATCH is running	

CORMOV is a general core-moving subroutine, called by the instruction sequence:

```

JMS CORMOV
CDF FROMFIELD
FROMADDR - 1
CDF TOFIELD
TOADDR - 1
- COUNT
    
```

while ERROR is the local error processing routine, called with a pointer to the appropriate error message in the accumulator.

The major pass 1 and pass 2 subroutines, described below, operate on the loader internal tables, whose format is presented later in this

LOADER PASS 2 (LOADER IMAGE BUILDER)

00000	Utility routines: Symbol table look-up, TTY message handler, OS/8 block I/O, MCTTBL processor.	FIELD 0
01400	Routine to print symbol map.	
02000	Pass 2	
03200	Binary buffer #1	
05200	Binary buffer #2	
07200	I/O device handlers	
07600	OS/8 Field 0 resident	
10000	RALF module text loads here if 8K.	FIELD 1
12000	Symbol table	
15400	Overlay length table	
16000	MCTTBL and MODTBL	
17200	Binary section table and binary buffer (LDBUFS) table	} symbol map output buffer
17400	ESD reference page	
17600	OS/8 Field 1 resident	
20000	Binary buffer #3, if >8K	FIELD 2
22000	Binary buffer #4, if >8K	
24000	Binary buffer #5, if >12K	
26000	Unused	
30000	RALF module text loads here if >12K	FIELD 3

chapter. The subroutines are presented in approximately the order that they occur in the source listing.

SETBPT Sets words BPTR and BPT2 to contain AC and AC+1, respectively.

TTYHAN Subroutine to unpack and print a TEXT message on the console terminal. TTYHAN is called by:

CDF CURRENT
 CIF 0
 JMS TTYHAN
 CDF MSGFIELD
 MSG

RTNOS8 Prints a fatal error message and then returns to the OS/8 monitor. A pointer to the message must follow the JMS RTNOS8.

IOHAN Used to execute all I/O under OS/8. The calling sequence is:

```
TAD (ACARG          /Optional
CDF CURRENT
CIF 0
JMS IOHAN
ADDR
ARG1
ARG2
ARG3
```

where ARG1, ARG2 and ARG3 are standard OS/8 device handler arguments and ADDR points to a three-word block in field 1 which contains the OS/8 unit number in word 1, the file length in word 2, and the starting block number in word 3.

If ACARG is zero, the indicated I/O operation is executed after the handler has been FETChed, if necessary. If ACARG=n (greater than zero), the handler for OS/8 unit n is FETChed, no I/O is done, and the four arguments that conclude the calling sequence are not needed.

ADVOVR Called to initialize the loader to accept a new input module. ADVOVR determines whether a new overlay or level is being started by accessing the module count table. If so, it sets various pointers and internal counters accordingly, rounds the previous overlay to terminate on a 200 word boundary, and updates the length of the previous level, if necessary, as the maximum of its constituent overlay lengths.

NXTOVR Called by ADVOVR when the next input module will be the first module in a new overlay.

SETCNT Initializes the pointers and counters used by ADVOVR. SETCNT is called once at the beginning of each pass.

LOOK Executes a symbol look-up in the loader symbol table. LOOK is called by:

```
TAD (Pointer to symbol name in
      RALF ESD format
JMS LOOK
RETURN here if not found
RETURN here if found
GPTR points to word following entry name
```

If the symbol is not found, it is inserted into the loader symbol table and GPTR is set to point to the word following the symbol name.

SYMMAP Produces the symbol map.

PUTSYM Enters an ESD symbol in the loader symbol table. PUTSYM calls LOOK to determine whether the symbol is already present in the symbol table and, if so, verifies that the symbol is not multiply defined. Otherwise, it copies the ESD data words into the symbol table entry, updates the length of the current overlay by the length associated with the symbol, and links the symbol to its parent symbol, if any.

FIT Fits a section into core by subtracting its length from the amount of core still available and substituting its load address for its length in the symbol table.

DO8S, FIT8S Fits an 8-mode section into core by calling FIT and then checking for field 1 overflow.

SETREF Extracts data from the ESD table of the current module and initializes the ESD reference page at 17400.

BLDTV Builds the transfer vector. A transfer vector entry is created for each subroutine in an overlay. This entry provides the information that the run-time system will require in order to load the overlay containing the referenced subroutine.

NEWORG Called whenever an origin is found in an input module, to map the location referenced by the origin into a block of the loader image file and an address within that block.

NEWBB Called whenever a new binary buffer is needed during loader image file construction. NEWBB scans a list of available buffers and dumps the content of the least recently accessed buffer to free up space for new data.

MERGE Relocates an input word pair and outputs it to the loader image file.

GETCTL Gets a control byte from the input module and increments its return address by the content of the control byte.


PUTBIN Inserts words, sequentially, into the current binary buffer. When the buffer is full, PUTBIN calls NEWBB to execute output to the loader image file and supply a new buffer.

TXTSCN Called once for each input module. TXTSCN reads and relocates an entire input module, executing calls to MERGE, PUTBIN and NEWORG as needed.

SYMBOL TABLE

The loader symbol table begins at location 12000 and contains room for 26 (decimal) permanent system symbol entries and 218 (decimal) user entries. Each entry is 7 words long, and provides the name and definition of a symbol. The table is organized in buckets according to the first character of the symbol, which must be A to Z, #, or blank (for blank COMMON). The table of bucket pointers begins at location 12000 with the pointer to bucket A, and consists of one word per bucket. This word contains a value of zero, if there are no symbols in the corresponding bucket, or else the address of the first symbol in the bucket.

Symbols within a bucket are arranged in alphabetical order, with each symbol entry pointing to the following entry, and the last entry pointing to zero. Thus, the symbol table appears as a set of threaded lists in core. The format of a symbol table entry is:



Several special symbols are created by the loader. The symbol #YLVLn, where n is an octal digit, describes overlay level n. This symbol table entry contains the length of level n during pass 1 and the starting address of level n during pass 2.

The symbol #YTRAP describes the trap vector, a method by which the run-time system controls automatic overlaying of user subroutines. Four words are allocated in the trap vector for each entry point in every overlay except overlay #MAIN. The symbol table entry for #YTRAP contains the accumulated length of the trap vector during pass 1 and the trap vector starting address during pass 2.

ESD CORRESPONDENCE TABLE (ESDPG)

The ESD correspondence table begins at location 17400 and contains 128 (decimal) 1-word entries. This table establishes the correspondence between the local ESD reference numbers used to reference a symbol inside a RALF module, and the address of that symbol in the loader symbol table. The nth entry in the ESD correspondence table points to the address of ESD symbol n.

BINARY BUFFER TABLE (LDBUFS)

The binary buffer table begins at location 17247 and contains from two to ten entries, depending upon the amount of memory available. Each entry is 4 words in length. The binary buffers function as windows into the loader image file, through which the loaded program is written onto mass storage. Each binary buffer is 8 pages (4 OS/8 blocks) in length. The loader tries to minimize the amount of "window turning" necessary to buffer the binary data by keeping a record of the last time each buffer was referenced. In this way,

when the content of a binary buffer must be dumped to make room for new data, the loader empties that buffer which was least recently used.

In addition, program loading is overlay oriented such that only one overlay is loaded at a time and while any specific overlay is being loaded, only origins inside that overlay are legal.

The format of a binary buffer table entry is:

Pointer to the binary buffer of "next earliest reference", i.e., the youngest buffer older than this buffer. Contains zero if this buffer is oldest.			WORD 1
Loader image block #. Contains zero if buffer has not been used.			WORD 2
Blocks left in current overlay. If <4, only part of buffer will be dumped.			WORD 3
Page address of buffer.	Buffer field bits	Unused	WORD 4

The number of binary buffers used varies with the amount of memory available as follows:

MEMORY AVAIL	NO. OF BUFFERS
8K	2
12K	4
16K	5
20K	7
24K	10 (decimal)
28K	10 (decimal)
32K	10 (decimal)


BINARY SECTION TABLE

The binary section table overlays the loader image header block (described under FRTS) after the latter has been written into the loader image file at the beginning of pass 2. Thus, the binary section table begins at location 17200 and contains eight 4-word entries. Each entry relates the core origin of one of the eight overlay levels to that level's position in the loader image file. The format of a binary section table entry is:

Unused	Field of level	WORD 1
Address of level		WORD 2
Relative block #		WORD 3
Length (in blocks)		WORD 4


OVERLAY TABLE (OVL'TBL)

The overlay table begins at location 15435 and contains room for 113 (decimal) 2-word entries. There is one entry for each overlay defined, including overlay MAIN, with each entry designating the length in words, of the corresponding overlay. The format of an overlay table entry is:



MODULE DESCRIPTOR TABLE (MODTBL)

The module descriptor table begins at location 16172 and contains room for 172 (decimal) 3-word entries. Each entry provides the information needed to locate an input module. The first MODTBL entry corresponds to the library file to be used in building the current loader image. Successive entries correspond to input modules and appear in the order that the modules were specified by the user, (i.e., in ascending order by level, and ascending by overlay within any given level.) At the end of pass 1, entries corresponding to individual library modules are appended to the end of the table, even though the library modules load into level MAIN. The table format is:




MODULE COUNT TABLE (MCTTBL)

The module count table begins at location 16000 and contains room for 122 (decimal) 1-word entries that give the (two's complement) module count for each overlay level. The table format is:

MCTTBL		1-word ENTRIES
LEVEL	MAIN	
	Ø	
LEVEL 1	OVERLAY 1	
LEVEL 1	OVERLAY 2	
LEVEL 1	OVERLAY 3	
LEVEL 1	OVERLAY n	
	Ø	
LEVEL 2	OVERLAY 1	
LEVEL 2	OVERLAY 2	
LEVEL 2	OVERLAY n	
	Ø	
LEVEL 3	OVERLAY 1	
	⋮	
LEVEL m	OVERLAY n	
	Ø	
	Ø	

If an overlay or level is not defined for a specific program, there is no module count table entry corresponding to that overlay or level.

The loader image file, produced by the loader and read as input by the run-time system, consists of a header block followed by a binary image of each level defined in the FORTRAN IV job.



The loader image file header block contains information in the following format:

LOCATION	CONTENTS
0	2 -- Identifies the file as a loader image file.
1-2	Initial SWAP arguments to load level MAIN.
3-4	Highest address used by core load, including overlays but not including OS/8 device handlers.
5	Loader version number.
6	Double-precision flag.
7-46	User overlay information table containing one 4-word entry per overlay level (the level MAIN entry is ignored) in the following format:

	Unused until SWAP time. Must be positive or zero.				WORD 1
Load address →	Page bits	Bits 4-5 unused	Field bits	Bits 9-11 unused	WORD 2
	Block number of this level, relative to header block.				WORD 3
	Length of overlays in this level, in blocks.				WORD 4

CHAPTER 4

THE FORTRAN IV RUN-TIME SYSTEM

The FORTRAN IV run-time system supervises execution of a FORTRAN job and provides an I/O interface between the running program and the OS/8 operating system. FRTS includes its own loader, which should not be confused with LOAD, the system loader. It executes with only one overlay, used to restore the resident monitor and effect program termination. The run-time system was designed to permit convenient modification or enhancement, and it is well documented in the assembly language source, available from the Software Distribution Center, which includes extensive comments.

One of the most valuable modifications to FRTS provides for the inclusion of background (or idle) jobs. When FORTRAN is waiting for I/O operations or the FPP to complete execution, the PDP-8 or PDP-12 processor is sitting in an idle loop. An idle job may be executed by the PDP-8 or PDP-12 CPU during this time, perhaps for the purpose of refreshing a CRT display, for example, or monitoring a controlled process. To indicate such a job, the idle wait loop must be modified to include a reference to the user's PDP-8 routine. The routine #IDLE in FRTS must be changed as part of the user's subroutine from

```
#IDLE,  JMP .+4      to      #IDLE,  SKP
          0                          ADDUSR
          CDF CIF                          FLDUSR
          JMS I .-2                          JMS I .-2
```

Devices issuing interrupts may be added to the interrupt skip chain so that FORTRAN checks the user's device as well as system devices. The original code is:

```
#INT,   JMP .+4
          0
          CDF CIF
          JMS I .-2
```

and must be changed, as above, to:

```
#INT,   SKP
        ADDUSR
        FLDUSR
        JMS I .-2
```

In both cases, ADDUSR should be the address of the user's routine, and FLDUSR should be the memory field of the user's routine.

The idle job is initiated by the subroutine HANG in the run-time system. Hang should only be called when the FORTRAN program must wait for an I/O device flag. The calling sequence is:

```
EXTERN #HANG

IOF           /Important.
CDF n        /Where n is current field.
CIF 0
JMS% HANG+1
ADDRSS

                /Return here with interrupts OFF
                /When device flag is raised.
```

```
HANG, ADDR #HANG
```

The word ADDRSS must point to a location in page 400 of the run-time system which must normally contain a JMP DISMIS. Three such locations have been provided for the user at #DISMS, #DISMS+1, and #DISMS+2. The selected location must be the location via which the interrupt caused by the desired flag is dismissed. No two flag routines should use the same dismiss location. The following program example illustrates these calling conventions. This routine may be used to drive a Teletype terminal via the PT08 option.

```

        EXTERN #ONQI
        EXTERN #DISMS
        FIELD1 GETCH      /JMS GETCH GETS A CHAR
        0                 /GETCH RUNS IN FIELD 1 ONLY
        ISZ FIRST
        JMP NOTFST
        JMSZ ONQI+1
        KSFI
        ADDR KSFSUB
        TAD DISMIS+1      /SET UP TO CALL HANG
        DCA HNGLOC
NOTFST, IOF
        TAD INCHR
        SZA CLA
        JMP GOT1
        CIF 0
HNGLOC, JMSZ HANG+1      /NO CHAR READY: HANG
        0                 /HANG RETURNS W/ IOF
GOT1,   TAD INCHR
        DCA FIRST
        DCA INCHR
        TAD FIRST
        ION
        JMP% GETCH
        /INTERRUPT ROUTINE
KSFSUB, 0                 /CALLED AS SUBROUTINE
        KRBI
        DCA INCHR
        CDF CIF 0
        JMP% DISMIS+1    /RETURN TO SYSTEM LOCATION
        /CONTAINING "JMP DISMIS"
INCHR,  0
ONQI,   ADDR #ONQI
HANG,   ADDR #HANG
DISMIS, ADDR #DISMS
FIRST,  -1

```

In most cases, it is easier to include references to the FORLIB module ONQI for adding a handler to the interrupt skip chain and ONQB for adding a job to the idle chain, instead of trying to modify #IDLE and #INT. ONQB provides slots for up to 9 idle jobs to be executed round-robin, and ONQI provides for up to 9 user flags to be tested on program interrupts.

FRTS entry points are listed, along with the core map, on the following pages. The FRTS calling sequence must be observed in any user subroutine. The formal calling sequence is illustrated below. In general, it can be used exactly as illustrated, changing only the section, entry, base page, index register and return location names.

FRTS CALLING SEQUENCE

SECT EXAMPL	/Section name. Your module may /require another section pseudo-op /such as FIELD1 or SECT8.
JA #EXSRT	/Jump to start of subroutine /Use # for first character
TEXT +EXAMPL+	/6 character section name for /error traceback (optional)
EXAMXR, SETX XREXAM	/Set up index registers /for this subroutine
SETB BPEXAM	/and its base page.
BPEXAM, F 0.0	/Base page
XREXAM, F 0.0	/Index registers 0-2
F 0.0	/Index registers 3-5 (optional)
EXTMP1, F 0.0	/Space between index registers
EXTMP2, F 0.0	/and the ORG for temporary
EXTMP3, F 0.0	/storage (optional)
ORG 10*3+BPEXAM	/Location 30 of base page
FNOP	/Force a two-word instruction
JA EXAMXR	/Jump to base page for /return to calling program
0	/Force a two-word instruction
EXMRTN, JA .	/Will be replaced by return jump
BASE 0	/Caller's base page
#EXSRT, STARTD	/Start of subroutine
FLDA 10*3	/Get return jump from caller's /base page
FSTA EXMRTN	/Save in return location for /this routine
FLDA 0	/Location 0 of caller's routine /is a pointer to the argument list
SETX XREXAM	/Change to EXAMPL's index registers
SETB BPEXAM	/Change to EXAMPL's base page
BASE BPEXAM	
FSTA BPEXAM	/Save the pointer
LDX 1,1	/Set up index register 1
FLDA% BPEXAM, 1	/Get address of argument list
FSTA EXTMP1	/Save the addresses
FLDA% BPEXAM, 1+	/of all passed arguments
FSTA EXTMP2	
FLDA% BPEXAM, 1+	
FSTA EXTMP3	/Continue for all arguments /to be picked up
.	
.	
STARTF	/Start three-word instructions
FLDA% EXTMP1	
.	
.	
FLDA% EXTMP2	
.	
.	/Continue to get arguments /as required in routine
JA EXMRTN	/Exit when done

RTS ENTRY POINT		USAGE AND COMMENTS
#UE	TRAP3 #UE	/Produces USER ERROR error message.
#ARGER or #ARGERR	TRAP4 #ARGER	/Produces BAD ARG error message.
#READO	TRAP3 #READO JA UNITNO JA FORMAT	/Initializes /formatted /read operation.
#WRITO	TRAP3 #WRITO JA UNITNO JA FORMAT	/Initializes /formatted /write operation.
#RUO	TRAP3 #RUO JA UNITNO	/Initializes unformatted /read operation.
#WUO	TRAP3 #WUO JA UNITNO	/Initializes unformatted /write operation.
#RDAO	TRAP3 #RDAO JA UNITNO JA RECNO	/Initializes /direct access /read operation.
#WDAO	TRAP3 #WDAO JA UNITNO JA RECNO	/Initializes /direct access /write operation.
#RFSV	TRAP3 #RFSV	/Passes a variable to or from the read/ /write processors via the floating AC.
#REND0	TRAP3 #REND0	/Terminates a read/write operation.
#ENDF	FLDA UNITNO TRAP3 #ENDF	/Executes an /end file,
#REW	or TRAP3 #REW	/rewind,
#BAK	or TRAP3 #BAK	/backspace (depending upon the entry used) /on the referenced I/O unit.
#DEF	TRAP3 #DEF JA UNITNO JA RECORDS JA FPNPR JA VARIABLE	/Opens a file /for direct access I/O. /(FPP numbers per record) /Refer to DEFINE FILE statement
#EXIT	JSR #EXIT	/Terminates current FORTRAN* IV job.
#SWAP	TRAP3 #SWAP ADDR	/Reads overlay OVLY into level LVL and /jumps to ADR. ADDR is given by: /ADDR=4000000*OVLY+100000*LVL+ADR
#8OR12		/=00000001 if the CPU is a PDP-12.
#IDLE		Address of background job, used by ONQB. Contains: JMP I (NULJOB /Replace by SKP 0 /Replace by addr of background job CDF CIF 0 /Replace by field of background job JMS I .-2 JMP .-4

CORE LAYOUT OF FRTS

	NON-FPP	FPP (Same as non-FPP unless indicated)
0000	Page zero (0120-0134 free)	
0200	Most entry points, character I/O handlers, interrupt service, and HANG routine	
0600	Format decoder; A, H, and ' format processors, and EXIT	
1400	REWIND, ENDFILE, BACKSPACE and general unit initialization. DATABL table (3 wds/unit)	
2000	I, E, F and G output	
2400	I, E, F and G input	
2600	X, L and T formats and GETHND routine	
3000	Char in and char out routines including OS/8 packing, editing and forms control	
3400	Binary and D. A. I/O, and DEFINE FILE processor	
3600	Overlay loader	
4000	Input line buffer, overlay and DSRN tables, FORMAT parenth pushdown list, /P processor and init flag clear	
4400	Floating-point utilities (shift, add, etc.) used even w/FPP	
4600	Error routine and messages	
5200	OS/8 handler area and part of FRTS loader initialization	
5600	FPP simulator	FPP start-up and trap routines
6000		B and D format I/O
6600	Floating-point package and part of LPT ring buffer	Floating-point package (never used) and part of LPT ring buffer
7400	Most of LPT ring buffer	
7600	OS/8 handler and field 0 resident	
10000	OS/8 User Service Routine	

12000	FRTS loader tables, IONTBL	Locations 12000 to 17400 are overlaid at execution time
12200	FRTS loader: main flow	
12400	program start-up ¹	
12600	initialize and configure system	
13000	Load OS/8 handlers and assign unit numbers to OS/8 files	
13400	Utility and error routines, error messages	
14000		
15600	FPP start-up and trap routines	Locations 14000 to 16777 are used to save lower field 0 during loading of device handlers and file specifications
16000	B and D format I/O	
16600	EAE Floating-point package	
17400	Termination routine	Locations 17400 to 17777 are written on SYS block 37 before program load and restored on termination
17600	OS/8 field 1 resident	

```

#INT          /Address of user interrupt location, used by ONQI:
              JMP .+4          /Replace with SKP
              0                /Replace with address of interrupt
                               processor
              CDF CIF 0        /Replace with field of interrupt processor
              JMS I .-2

#DISMS        /Addresses first of three JMP DISMIS instructions for
              use by specialized I/O routines.

#HANG         /Addresses I/O dismiss routine.

#RETRN       /Provides return from TRAP3.

```

¹Program start-up moves OS/8 handler to top of core, writes field 1 resident onto SYS, and termination routine goes to FRTS to load program.

DSRN TABLE

The DSRN table controls files and I/O devices used under OS/8 FORTRAN IV ASCII, binary and direct access I/O operations, including BACKSPACE, REWIND, and END FILE operations. The exact meaning of the initials DSRN is one of the great, unanswered questions of FORTRAN IV development and, as such, has considerable historical interest. The DSRN table provides room for 9 entries; each entry is 9 words in length, and contains the following data:

- WORD 1: (HAND) Handler entry point. If this value is positive, the I/O device handler is a FORTRAN internal (character-oriented) handler, and the remainder of the DSRN table entry is ignored. If the value is negative, the handler is an OS/8 device handler whose entry point is the two's complement of the value. Entry points always fall in the range [7607, 7777] for resident handlers or [5200, 5377] for non-resident handlers. Space for non-resident handlers is allocated downward from the top of memory, and the handlers are moved into locations 5200 to 5577 before being called.
- WORD 2: (HCODEW) Handler code word. Bits 0-4 of this word specify the page into which the device handler was loaded, while bits 6-8 specify the memory field. If all of bits 0-8 are zero, the handler is permanently resident. When any of these bits are non-zero, the data is used to determine which handler, if any, currently occupies locations 5200-5577. This eliminates unnecessarily moving the content of memory. Bit 10 is set if forms control has been inhibited on the I/O unit. Bit 11 is set if the device handler can execute with the interrupt system enabled. The data in bits 10 and 11 is obtained from the IOWTBL table in the FRTS loader.
- WORD 3: (BADFLD) Buffer address and field. Bits 0-4 address the memory page at which the I/O buffer for this unit begins, while bits 6-8 specify the memory field. Unlike the FORTRAN internal I/O unit buffers, OS/8 device handler buffers always occupy two full pages of memory. Buffer space is allocated upward from the top of the FORTRAN program.
- WORD 4: (CHRPTR) Character pointer.
- WORD 5: (CHRCTR) Character counter. Words 4 and 5 of each DSRN table entry define the current character/position in the I/O buffer as follows:

Value of CHRCTR	Character position	Next value of CHRCTR	Next value of CHRPTR	Special Conditions
-3	Bits 4-11 of word addressed by CHRPTR	-2	CHRPTR + 1	Refresh buffer if input operation and CHRPTR mod 256=0
-2	"	-1	"	none
-1	Bits 0-3 of words addressed by CHRPTR-2 and CHRPTR-1	-3	CHRPTR	Dump buffer if output operation and CHRPTR mod 256=0

WORD 6: (STBLK) Starting block of file.

WORD 7: (RELBLIC) Current relative block of file. That is, block to be accessed next.

WORD 8: (TOTBLK) Length of file in blocks.

WORD 9: (FFLAGS) Status flags:

Bit 0 - Has been written flag. Set to 1 if unit has received output since last REWIND.

Bit 1 - Formatted I/O flag. Set to 1 if an ASCII I/O operation has occurred since last REWIND.

Bit 2 - Unformatted I/O flag. Set to 1 if a binary or direct access I/O operation has occurred since last REWIND. Bits 1 and 2 are never set simultaneously.

Bit 11- END FILEd flag. Set to 1 if unit has been END FILEd. Bit 11 is not cleared by a REWIND.

When any active unit is selected for an I/O operation, the DSRN table entry for that unit is moved into 9 words on page 0. These 9 words are tagged with the labels cited above. Upon completion of the I/O operation, the 9 words are moved from page 0 back into the DSRN table.

/PAGE ZERO FOR FORTRAN IV RTS

00000	0000	*0		/INTERRUPT STUFF
00000	0000	0		
00001	5402	JMP I	.+1	
00002	0400	INTRPT		
00003	5165	LPGET,	LPBUFR	/LINE PRINTER RING BUFFER FETCH
00004	0000	TOCHR,	0	/TELETYPE STATUS WORD
00005	0000	KBDCHR,	0	/KEYBOARD INPUT CHARACTER
00006	0000	POCHR,	0	/P.T. PUNCH COMPLETION FLAG
00007	0000	RDRCHR,	0	/P.T. READER STATUS
00010	0000	FMTPIX,	0	/XR USED TO INDEX FORMAT PARENTH
00011	3777	INXR,	INBUFR-1	/XR USED TO GET CHARS FROM INPUT
00012	0000	XR,	0	
00013	0000	XRI,	0	
	0016	*16		
00016	0000	VEOFWS,	0	/USED BY "EOFCHK" TO STORE VARIABLE ADDRESS
00017	0000		0	/*K* MUST BE IN AUTO - XR
00020	0000	T,	0	/TEMPORARY
00021	0000	DFLG,	0	/0 = F.P., 1 = D.P.
00022	0000	INST,	0	/CURRENT INSTRUCTION WORD

/IOH PAGE ZERO LOCATIONS

00023	0000	RWFLAG,	0	/READ/WRITE FLAG
00024	0000	FMTTYP,	0	/TYPE OF CONVERSION BEING DONE
00025	0000	EOLSW,	0	/EOL SW ON INPUT - CHAR POS ON OUT
00026	0000	N,	0	/REPEAT FACTOR
00027	0000	W,	0	/FIELD WIDTH
00030	0000	D,	0	/NUMBER OF PLACES AFTER DECIMAL
00031	0000	DATCDF,	0	/SUBROUTINE TO CHANGE DATA FIELD
00032	0000	DATAF,	0	/CONTAINS VARIOUS CDF'S
00033	5431	JMP I	DATCDF	/RETURN
00034	5013	ERR,	ERROR	/POINTER TO ERROR ROUTINE
00035	0000	FATAL,	0	/FATAL ERROR FLAG - 0=FATAL
00036	5000	MCDF,	MAKCDF	

/FPP PARAMETER TABLE LOCATIONS:

00037	0000	APT,	0	/VARIOUS FIELD BITS FOR FPP
00040	5313	PC,	DPIEST	/FPP PROGRAM COUNTER
00041	0000	XRBASE,	0	/FPP INDEX REGISTER ARRAY ADDRESS
00042	0000	BASADR,	0	/FPP BASE PAGE ADDRESS
00043	0000	ADR,	0	/ADDRESS TEMPORARY
00044	0000	ACX,	0	
00045	0000	ACH,	0	/** FLOATING ACCUMULATOR **
00046	0000	ACL,	0	
00047	0000	EAC1,	0	
00050	0000	EAC2,	0	/** FOR EXTENDED PRECISION OPTION **
00051	0000	EAC3,	0	

/FLOATING POINT PACKAGE LOCATIONS

00052	0000	AC0,	0	
00053	0000	AC1,	0	/FLOATING AC OVERFLOW WORD
00054	0000	AC2,	0	/OPERAND OVFLOW WORD
00055	0000	OPX,	0	
00056	0000	OPH,	0	/** FLOATING OPERAND REGISTER **
00057	0000	OPL,	0	

/RTS I/O SYSTEM LOCATIONS

00060	0000	FMTBYT,	0	/FORMAT BYTE POINTER
00061	0000	IFLG,	0	/I FOEMAT FLAG
00062	0000	GFLG,	0	/G FORMAT FLAG
00063	0000	EFLG,	0	/E FORMAT FLAG - SOMETIMES ON FOR
00064	0000	OD,	0	
00065	0000	SCALE,	0	
00066	0000	PFACT,	0	/P-SCALE FACTOR
00067	0000	PFACTX,	0	/TEMP FOR PFACT
00070	0000	INESW,	0	/EXPONENT SWITCH
00071	0000	CHCH,	0	
00072	0000	FMTNUM,	0	/CONTAINS ACCUMULATED NUMERIC VALUE
00073	0000	CTCINH,	0	/tC INHIBIT FLAG
00074	0320	PTTY,	TTY	/POINTER TO TTY HANDLER - USED BY
00075	0000		0	/ SO FORMS CONTROL WILL WORK ON
00076	6001	FPNXT,	ICYCLE	/USED AS INTERPRETER ADDRESS IF

/DSRN IMAGE

00077	0000	HAND,	0	/HANDLER ENTRY POINT
00100	0000	HCODEW,	0	/HANDLER LOAD ADDR & FIELD + IOFFL
00101	0000	BADFLD,	0	/BUFFER ADDRESS AND FIELD
00102	0000	CHRPTR,	0	/ACTUALLY A WORD POINTER
00103	0000	CHRCTR,	0	/COUNTER - RANGES FROM -3 TO -1
00104	0000	STBLK,	0	/STARTING BLOCK OF FILE
00105	0000	RELBLK,	0	/CURRENT RELATIVE BLOCK NUMBER
00106	0000	TOTBLK,	0	/LENGTH OF FILE
00107	0000	FFLAGS,	0	/FILE FLAGS: /BIT 0 - "HAS BEEN WRITTEN" FLAG /BITS 1-2 - FORMATTED/UNFORMATTED /BIT 11 - "END-FILED" FLAG
00110	0000	BUFFLD,	0	/ROUTINE TO SET DF TO BUFFER FIELD
00111	7402	BUFCDF,	HLT	
00112	5510		JMP I	BUFFLD
00113	0000	FGPBF,	0	/THESE THREE WORDS ARE USED
00114	0000	BIOPTR,	0	/TO FETCH AND STORE FLOATING POINT
00115	0000		FEXIT	/FROM RANDOM MEMORY
	0200		PAGE	

/STARTUP CODE

```

00200 2203 FTEMP2, ISZ      .+3      /ALSO USED AS I/O F.P. TEMPORARY
00201 6213          CDF CIF 10
00202 5603          JMP I      .+1
00203 2200 VDATE,  RTSLDR      /USED TO STORE OS/8 DATE

```

/RTS ENTRY POINTS - "VERSION INDEPENDENT"

```

00204 5777 VUERR,  JMP I  (USRERR /USER ERROR
                                /** LOADER MUST DEFINE #ARGER AS
00205 4434 VARGER, JMS I  ERR      /LIBRARY ARGUMENT ERROR
00206 2023 VREND0, ISZ  RWFLAG  /END OF I/O LIST
00207 5634 VRFSV,  JMP I  GETLMN  /I/O LIST ARG ENTRY - COROUTINE
00210 5776 VBAK,   JMP I  (BKSPC  /"BACKSPACE" ROUTINE
00211 5775 VENDF,  JMP I  (ENDFL  /"END FILE" ROUTINE
00212 5774 VREW,   JMP I  (RWIND  /"REWIND" ROUTINE
00213 5773 VDEF,   JMP I  (DFINE  /"DEFINE FILE" ROUTINE
00214 7330 VWUO,   AC4000 /UNFORMATTED WRITE
00215 5772 VRUO,   JMP I  (RWUNF  /UNFORMATTED READ
00216 7330 VWDAO, AC4000 /DIRECT ACCESS WRITE
00217 5771 VRDAO,  JMP I  (RWDACC /DIRECT ACCESS READ
00220 7330 VWRITO, AC4000 /FORMATTED (ASCII) WRITE
00221 5770 VREADO, JMP I  (RWASCI /FORMATTED (ASCII) READ
00222 5767 VSWAP,  JMP I  (SWAP   /OVERLAY PROCESSOR
00223 3000 VEXIT,  TRAP3; CALXIT /"STOP" ROUTINE - ENTERED IN FPP
00224 1317
00225 0000 VBOR12, 0;0      /0;1 IF CPU IS A PDP-12
00226 0000
00227 5766 VBACKG, JMP I  (NULLJB /BACKGROUND JOB DISPATCHER
00230 0000
00231 6203          CDF CIF 0      /USED BY ROUTINE "ONQB" IN LIBRARY
00232 4630          JMS I      .-2
00233 5227          JMP      VBACKG

```

/IOH GET VARIABLE ROUTINE.

```

/THIS ROUTINE MAKES THE FORMATTED I/O PROCESSOR AND THE
/PROGRAM CO-ROUTINES (DEF(COROUTINE)= 2 ROUTINES EACH
/ IS A SUBROUTINE). ON ENTRY FAC=INPUT NUMBER
/IF I/O IS A READ, ON RETURN FAC=OUTPUT NUMBER IF I/O

```

```

00234 0000 GETLMN, 0
00235 5577 VRETRN, JMP I  [RETURN

```

All FORTRAN IV mass storage I/O is performed in terms of OS/8 blocks, including direct access I/O. Hence, all FORTRAN IV files conform to OS/8 standard ASCII file format. When a formatted READ or WRITE is requested, the data is converted to or from 8-bit binary representation according to the FORMAT statement associated with the READ or WRITE. Standard OS/8 file format packs three 8-bit characters into two 12-bit words as follows:

MASS STORAGE		CORE	
WORD 3 bits 0-3	WORD 1	WORD 1	
WORD 3 bits 4-7	WORD 2	WORD 2	
		WORD 3	

Unformatted (i.e. direct access) READ and WRITE operations also operate on standard OS/8 format files, with each statement causing one FORTRAN IV record to be read or written. A FORTRAN IV record must contain at least one OS/8 block, and always contains an integral number of blocks. The number of variables contained in a 1-block record depends upon the content and format of the I/O list, as follows:

<u>Format type</u>	<u>Number of 12-bit Words/Variable</u>	<u>Number of Variables/Block</u>
Integer	3	85
Real	3	85
Double precision	6	42 1/2
Complex	6	42 1/2

It is possible to mix any types of data in an I/O list; however, no more than 85 variables may be stored in one OS/8 block. The number of blocks required for a FORTRAN IV record depends, therefore, upon the number of variables in the I/O list, and may be minimized by supplying every direct access WRITE with sufficient data to nearly fill an integral number of blocks without overflowing the last block.

The last word in every file block contains a block count sequence number and is not available for data storage. FRTS assigns block count numbers sequentially, beginning with 1, whenever a file is written. Block count numbers must be maintained by the user when FORTRAN IV files are created outside of an OS/8 FORTRAN IV environment. While reading a binary file, FRTS checks the block count sequence numbers on input blocks and ignores any block whose sequence number is larger than expected. Sequence number checking is disabled during direct access READ operations.

When FRTS is loaded and started, the initialization routines determine what optional hardware, such as FPP-12 Floating Point Processor or KE8E Extended Arithmetic Element, is present in the running hardware configuration. The initialization routines then modify FRTS to use the optional hardware, if available. When an FPP is present in the system and it becomes desirable to disable the FPP under FRTS, this may be accomplished by changing the content of location 12621 from 6555 to 7200. The extended arithmetic element may be disabled in the same manner by changing the content of FRTS location 12623 from 7413 to 7200. These changes must be made before FRTS is started. The OS/8 monitor GET and ODT commands provide an excellent mechanism for changes of this type.

The FRTS internal line printer handler uses a linked ring buffer for maximum I/O buffering efficiency. The buffer consists of several contiguous sections of memory, linked together by pointers. All of these buffer segments are located above 04000, so that the pointers are readily distinguishable from buffered characters. The entire 07400 page is included in the line printer ring buffer. If it becomes desirable to modify FRTS by patching or reassembly, most of the 07400 page may be reclaimed from the buffer by changing the

content of location 07402 from 7577 to 5164. This frees up locations 07403 to 07577 for new code and still leaves about eighty character positions in the LPT ring buffer.

Because FRTS executes with the processor interrupt system enabled, it may hang up on hardware configurations that include equipment capable of generating spurious program interrupts. In addition, any OS/8 I/O device handler that exits without clearing all device flags may cause troublesome interrupts when it is assigned as a FORTRAN I/O unit under FRTS. To counteract these potential problems, FRTS provides certain areas that are reserved for inclusion of user-generated code designed to clear device flags and/or inhibit spurious interrupts.

A string of NOP instructions beginning at location 04020 is executed during FRTS initialization, just before the interrupt system is enabled. When the /H option is specified to FRTS, the system halts after these NOPs have been executed and the interrupt system has been enabled. Another string of NOPs occupying the eight locations from 03746 to 03755 is executed after every call to an OS/8 device handler. Any of these NOP instructions may be replaced by flag-handling or interrupt-servicing code. If additional memory locations are required, they may be obtained by replacing some of the code from locations 04007 to 04017 with flag-handling code. Locations 04007-17 are used to clear flags associated with LAB-8/E peripheral devices.

Due to memory limitations, it is not possible to add internal I/O device handlers to the four internal handlers supplied with the system. However, FORTRAN I/O unit 0, which is not defined by the ANSI standard, may be specified for terminal I/O via the internal console terminal handler. I/O unit 0 is not re-assignable.

/INTERRUPT DRIVEN I/O HANDLERS

```

00236 0000 LPT, 0 /RING-BUFFERED - LP08 OR LS8E
00237 0176 AND [377 /JUST IN CASE
00240 7450 LPTSNA, SNA
00241 5765 JMP I (IOERR /CANNOT BE USED FOR INPUT
00242 6002 IOF
00243 3667 DCA I LPPUT
00244 1003 TAD LPGET
00245 7041 CIA
00246 1267 TAD LPPUT
00247 7640 SZA CLA /IS LPT QUIET?
00250 5253 JMP .+3 /NO
00251 1667 TAD I LPPUT
00252 6666 LLS /YES - START 'ER UP
00253 7201 CLA IAC
00254 6665 LIE /ENABLE LPT INTERRUPTS
00255 1267 TAD LPPUT /I IN AC, REMEMBER?
00256 3267 DCA LPPUT
00257 1667 TAD I LPPUT
00260 7510 SPA
00261 5256 JMP .-3 /NEGATIVE NUMBERS ARE BUFFER LINKS
00262 7640 SZA CLA /ANY ROOM LEFT IN BUFFER?
00263 4764 JMS I (HANG
00264 0436 LPUHNG /WAIT FOR LINE PRINTER
00265 6001 ION /TURN INTERRUPTS BACK ON
00266 5636 JMP I LPT /RETURN

00267 5165 LPPUT, LPBUFR

00270 0000 PTP, 0 /PAPER TAPE PUNCH HANDLER
00271 7450 SNA
00272 5765 JMP I (IOERR /INPUT IS ERROR
00273 3236 DCA LPT /SAVE CHAR
00274 6002 IOF
00275 1006 TAD POCHR /IF PUNCH IS NOT IDLE,
00276 7640 SZA CLA /WE DISMISS JOB
00277 4764 JMS I (HANG
00300 0502 PPUHNG /WAIT FOR PUNCH INTERRUPT
00301 1236 TAD LPT
00302 6026 PLS /OUTPUT CHAR
00303 3006 DCA POCHR /SET FLAG NON-ZERO
00304 6001 ION
00305 5670 JMP I PTP

```

/*K* THE FOLLOWING ADDRESSES GET FALLEN INTO & MUST BE SMAL

```

IFNZRO PPUHNG&7000 <<<ERROR<<>
IFNZRO ITUHNG&7000 <<<ERROR<<>
IFNZRO KBUHNG&7000 <<<ERROR<<>
IFNZRO RDUHNG&7000 <<<ERROR<<>
IFNZRO LPUHNG&7000 <<<ERROR<<>

```

/INTERRUPT-DRIVEN PTR AND TELETYPE HANDLER

00306	0000	PTR,	Ø		/CRUDE READER HANDLER
00307	7640		SZA	CLA	
00310	5765		JMP	I	(IOERR /OUTPUT ILLEGAL TO PTR
00311	6002		IOF		
00312	6014		RFC		/START READER
00313	4764		JMS	I	(CHANG
00314	0510		RDUHNG		/HANG UNTIL COMPLETE
00315	1007		TAD	RDRCHR	/GET CHARACTER
00316	6001		ION		
00317	5706		JMP	I	PTR /RETURN
00320	0000	TTY,	Ø		/BUFFERS 2 CHARS ON OUTPUT, 1 ON
00321	6002		IOF		/DELICATE CODE AHEAD
00322	7450		SNA		/INPUT OR OUTPUT?
00323	5342		JMP	KBD	/INPUT
00324	3236		DCA	LPT	/OUTPUT - SAVE CHAR
00325	1004		TAD	TOCHR	/GET TTY STATUS
00326	7740		SMA	SZA	CLA /G.T. Ø MEANS A CHAR IS BACKED UP
00327	4764		JMS	I	(CHANG
00330	0451		TTUHNG		/WAIT FOR LOG JAM TO CLEAR
00331	1004		TAD	TOCHR	/NO CHAR BACKED UP - SEE IF TTY
00332	7104		CLL	RAL	/"BUSY" FLAG IN LINK - INTERRUPTS
00333	7230		CLA	CML	RAR /COMPLEMENT OF BUSY IN SIGN
00334	1236		TAD	LPT	/GET CHAR
00335	7510		SPA		/IF TTY NOT BUSY,
00336	6046		TLS		/OUTPUT CHAR
00337	3004		DCA	TOCHR	/STORE POS OR NEG, BACKED UP
00340	6001	TTYRET,	ION		/TURN INTERRUPTS BACK ON
00341	5720		JMP	I	TTY /AND LEAVE

00342	1005	KBD,	TAD	KBDCHR	/HAS A CHARACTER BEEN INPUT?
00343	7650		SNA	CLA	
00344	4764		JMS	I	(CHANG
00345	0465		KBUHNG		/NO - RUN BACKGROUND UNTIL ONE IS
00346	1005		TAD	KBDCHR	/GET CHARACTER
00347	3236		DCA	LPT	
00350	3005		DCA	KBDCHR	/CHEAR CHARACTER BUFFER
00351	1236		TAD	LPT	
00352	5340		JMP	TTYRET	/RETURN WITH INTERRUPTS ON
00353	6554	KILFPP,	FPHLT		/BRING FPP TO A SCREECHING HALT
00354	2353		ISZ	.-1	
00355	5354		JMP	.-1	/WAIT FOR IT TO STOP
00356	6552		FPICL		/CLEAN UP MESS HALT HAS MADE IN FPP
00357	7430		SZL		/↑C OR ↑B?
00360	5763		JMP	I	(7600 /↑C - HIYO SILVER, AWAY!
00361	6032		KCC		/CLEAR KBD FLAG ON ↑B
00362	4434	CTLBER,	JMS	I	ERR /*** THIS MAY BE DANGEROUS! **

/INTERRUPT SERVICE ROUTINES

```

00400 3322 INTRPT, DCA      INTAC
00401 7010          RAR
00402 3323          DCA      INTLNK
00403 5207 VINT,    JMP      .+4    /** MUST BE AT 403 **
          IFNZRO VINT-403    <--- CHANGE LOADER!!!>
00404 0000          0
00405 6203          CDF CIF 0      /USER INTERRUPT ROUTINE GOES HERE
00406 4604          JMS I   .-2

00407 6551          FPINT          /CHECK FOR FPP DONE
00410 5215          JMP      LPTST
00411 5314 FPUHNG, JMP      DISMIS /ALWAYS GOES TO RESTRIT

00412 5314 VDISMS, JMP      DISMIS /FOR USE BY USERS
00413 5314          JMP      DISMIS
00414 5314          JMP      DISMIS

00415 6661 LPTST,  LSF
00416 5240          JMP      NOTLPT
00417 6662 LPTLCF, LCF          /CLEAR FLAG
00420 1403          TAD I   LPGET
00421 7650          SNA CLA          /CHECK FOR SPURIOUS INTERRUPT
00422 5314 JMPDIS, JMP      DISMIS /GO AWAY IF SO
00423 3403          DCA I   LPGET /ZERO CHAR JUST OUTPUT
00424 2003          ISZ      LPGET
00425 1403          TAD I   LPGET
00426 7510          SPA
00427 3003          DCA      LPGET /TAKE CARE OF BUFFER LINKS
00430 7450          SNA
00431 1403          TAD I   LPGET /MAKE SURE CHAR IS IN AC
00432 7440          SZA          /IS THERE A CHARACTER?
00433 6666          LLS          /YES - PRINT IT
00434 7200          CLA
00435 6661          LSF          /CHECK FOR IMMEDIATE FLAG
00436 5314 LPUHNG, JMP      DISMIS /NO - MAYBE RESTART PROGRAM
00437 5217          JMP      LPTLCF /YES - LOOP

00440 6041 NOTLPT, ISF          /CHECK TTY
00441 5252          JMP      NOTTTY
00442 6042          TCF          /CLEAR FLAG
00443 1004          TAD      TOCHR /GET TTY STATUS
00444 7540          SMA SZA /IF THERE IS A CHARACTER WAITING,
00445 6046          TLS          /OUTPUT IT.
00446 7740          SMA SZA CLA /CHANGE "WAITING" TO "BUSY",
00447 7130          STL RAR /"BUSY" TO "IDLE".
00450 3004          DCA      TOCHR
00451 5314 TTUHNG, JMP      DISMIS

```

/KBD AND PTP INTERRUPTS

```

00452 6031 NOTTTY, KSF
00453 5276          JMP      NOTKBD
00454 1175          TAD      I200
00455 6034          KRS
00456 3005          DCA      KBDCHR /USE KRS TO FORCE PARITY BIT
00457 1005          TAD      KBDCHR /AND ALSO SO THAT ↑C WILL STILL
00460 1377          TAD      (-202 /CHECK FOR ↑C OR ↑B
00461 7110          CLL RAR
00462 7650          SNA CLA
00463 5266          JMP      CTCCTB /YUP - TAKE SOME DRASTIC ACTION
00464 6032          KCC      /DATA CHARACTER - CLEAR FLAG
00465 5314 KBUHNG, JMP      DISMIS

00466 1073 CTCCTB, TAD      CTCINH
00467 7650          SNA CLA /ARE WE IN A HANDLER?
00470 5366          JMP      NOTINH /NO
00471 1323          TAD      INTLNK
00472 7104          CLL RAL /YES - RETURN WITH INTERRUPTS OFF
00473 1322          TAD      INTAC  /TRUST IN GOD AND RTS
00474 6244          RMF
00475 5400          JMP I 0

00476 6021 NOTKBD, PSF
00477 5303          JMP      NOTPTP
00500 6022          PCF
00501 3006          DCA      POCHR /P.T. PUNCH INTERRUPT - CLEAR FLAG
00502 5314 PPUHNG, JMP      DISMIS /CLEAR SOFTWARE FLAG

00503 6011 NOTPTP, RSF
00504 5311          JMP      LPTERR
00505 1175          TAD      I200
00506 6012          RRB      /GET RDR CHAR
00507 3007          DCA      RDRCHR
00510 5314 RDUHNG, JMP      DISMIS

00511 6663 LPTERR, LSE
00512 7410          SKP
00513 6667          LIF      /DISABLE LP08 INTERRUPTS IF ERROR
00514 1323 DISMIS, TAD      INTLNK
00515 7104          CLL RAL
00516 1322          TAD      INTAC  /RESTORE AC AND LINK
00517 6244          RMF
00520 6001          ION
00521 5400          JMP I 0 /RETURN FROM THE INTERRUPT

00522 0000 INTAC, 0
00523 0000 INTLNK, 0

```

/BACKGROUND INITIATE/TERMINATE ROUTINE

```

00524 0000 HANG, 0 /ALWAYS CALLED WITH INTERRUPTS OFF!
00525 1724 TAD I HANG /GET POINTER TO UNHANGING LOCATION
00526 3371 DCA UNHANG
00527 6214 RDF /GET FIELD CALLED FROM
00530 1332 TAD HCIDF0
00531 3364 DCA HNGCDF /SAVE FOR RETURN
00532 6203 HCIDF0, CDF CIF 0
00533 1376 TAD (JMP RESTRT /CHANGE THE "JMP DISMIS"
00534 3771 DCA I UNHANG /TO A "JMP RESTRT"
00535 1373 TAD BACKLK
00536 7104 CLL RAL
00537 1372 TAD BACKAC /SET UP BACKGROUND AC AND LINK
00540 6202 BAKCIF, CIF 0
00541 6201 BAKCDF, CDF 0
00542 6001 ION
00543 5774 JMP I BACKPC /INITIATE BACKGROUND

/ COME HERE WHEN THE HANG CONDITION HAS GONE AWAY

00544 1222 RESTRT, TAD JMPDIS /RESTORE THE UNHANG LOCATION
00545 3771 DCA I UNHANG
00546 1322 TAD INTAC /SUSPEND THE BACKGROUND
00547 3372 DCA BACKAC
00550 1323 TAD INILNK
00551 3373 DCA BACKLK
00552 1000 TAD 0
00553 3374 DCA BACKPC
00554 6234 RIB
00555 0174 AND [70
00556 1332 TAD HCIDF0
00557 3340 DCA BAKCIF
00560 6234 RIB
00561 4436 JMS I MCDF /*K* OK SINCE BACKGROUND DOESN'T
00562 3341 DCA BAKCDF
00563 2324 ISZ HANG
00564 7402 HNGCDF, HLT
00565 5724 JMP I HANG /INTERRUPTS ARE OFF - RETURN

00566 1222 NOTINH, TAD JMPDIS /IN CASE WE WERE HUNG, WE DON'T
00567 3771 DCA I UNHANG /TO GET "UNHUNG" OUT OF THE ERROR
00570 5775 JMP I (KILFPP /KILL FPP AND GO TO EXIT OR ERROR

00571 0000 UNHANG, 0
00572 0000 BACKAC, 0
00573 0000 BACKLK, 0
00574 0227 BACKPC, VBACKG
0524 VHANG= HANG
IFNZRO VHANG-0524 <-- CHANGE LOADER!>

00575 0353
00576 5344
00577 7576
0600 PAGE

```

The FRTS /P option provides a mechanism whereby the core image generated from a FORTRAN program may be punched onto paper tape in binary loader format. This permits the loader image to be executed on a hardware configuration that does not include mass-storage devices. To use the /P option, specify /P to FRTS and assign a device or file as FORTRAN I/O unit 9. Assigning the paper tape punch as unit 9 causes the image to be punched out directly; however, it may be desirable to direct the binary output to an intermediate file for later transfer to paper tape via OS/9 PIP. In any event, FRTS returns to the monitor once the core image has been transferred.

The output file is a binary image of memory locations 000000 to 07577 and 100000 up to the highest location used by the FORTRAN load. The content of each field is punched separately with its own checksum and leader/trailer.


With the BIN loader resident in field 0, load the binary tape produced under the /P option by reading each segment separately and verifying the checksum as each memory field is loaded. When all segments have been read into memory, start execution at location 002000. The following restrictions apply:

1. OS/8 device handlers which have been assigned FORTRAN I/O unit numbers are not necessarily punched out. For this reason, I/O unit assignments other than in the form /n=m should be avoided.
2. With respect to the presence of an FPP and/or EAE, the configuration on which the image is punched must be identical to the configuration on which it is to be run. If the punching configuration contains hardware that is absent from the target configuration, this hardware must be disabled under FRTS. If the target configuration contains hardware that is absent from the punching configuration, the extraneous hardware will not be used.
3. The statements STOP and CALL EXIT cause a core load produced under the /P option to halt. Any fatal error flagged during punching or execution causes error traceback followed by a halt. Do not press CONTInue in response to either of these machine halts.

A FORTRAN IV program is terminated in one of three ways:

1. A fatal error condition is flagged (CTRL/B) is processed as a fatal error.
2. CTRL/C is recognized, or the CPU is halted and re-started in 07600.
3. A STOP, CALL EXIT, or (under RALF) JSR #EXIT statement is executed.

The sequence of events that results in program termination proceeds as follows:



At point A, FRTS executes the following operations.

1. Read termination routine into memory.
2. Read OS/8 field 0 resident from block 37 of SYS.
3. Jump into termination routine at location 17400.
4. Restore normal content of locations 07600 and 07605 (in OS/8 resident).
5. If configuration is an in-core TD8E DEctape system, restore second part of TD8E handler from n7600 to 27600.
6. Wait for TTY to finish all pending I/O. If BATCH is running, print LF on TTY and LPT.
7. If normal termination flag is set, close any output files that were opened by the FRTS loader.
8. Return to OS/8 monitor via location 07605.

6600 FPPKG= . /FOR EAE OVERLAY

/23-BIT FLOATING PT INTERPRETER
 /W.J. CLOGHER, MODIFIED BY R.LARY FOR FORTRAN

```

06600 0000 LPBUF2, ZBLOCK 16
06616 7160 LPBUF3

06617 0000 ALIBMP, 0 /*** UTILITY SUBROUTINE
06620 7240 STA
06621 1044 TAD ACX
06622 3044 DCA ACX
06623 4542 JMS I [ALI
06624 5617 JMP I ALIBMP

/FLOATING MULTIPLY-DOES 2 24X12 BIT MULTIPLIES
06625 4777 DDMPY, JMS I (DARGET
06626 7410 SKP
06627 4776 FFMPY, JMS I (ARGET /GET OPERAND
06630 4304 JMS MDSET /SET UP FOR MPY-OPX IN AC ON RETN.
06631 1044 TAD ACX /DO EXPONENT ADDITION
06632 3044 DCA ACX /STORE FINAL EXPONENT
06633 3304 DCA MDSET /ZERO TEM STORAGE FOR MPY ROUTINE
06634 3054 DCA AC2
06635 1045 TAD ACH /IS FAC=0?
06636 7650 SNA CLA
06637 3044 DCA ACX /YES-ZERO EXPONENT
06640 4334 JMS MP24 /NO-MULTIPLY FAC BY LOW ORDER OPR.
06641 1056 TAD OPH /NOW MULTIPLY FAC BY HI ORDER MULT
06642 3057 DCA OPL
06643 4334 JMS MP24
06644 1054 TAD AC2 /STORE RESULT BACK IN FAC
06645 3046 DCA ACL /LOW ORDER
06646 1304 TAD MDSET /HIGH ORDER
06647 3045 DCA ACH
06650 1045 TAD ACH /DO WE NEED TO NORMALIZE?
06651 7004 RAL
06652 7710 SPA CLA
06653 4217 JMS ALIBMP /YES-DO IT FAST
06654 1053 TAD AC1
06655 7710 SPA CLA /CHECK OVERFLOW WORD
06656 2046 ISZ ACL /HIGH BIT ON - ROUND RESULT
06657 5265 JMP MDONE
06660 2045 ISZ ACH /LOW ORDER OVERFLOWED - INCREMENT
06661 1045 TAD ACH
06662 7510 SPA /CHECK FOR OVERFLOW TO 4000 0000
06663 5775 JMP I (SHRI /WE HANDLE A SIMILIAR CASE IN
06664 7200 CLA
    
```

```

06665 3053 MDONE, DCA ACI /ZERO OVERFLOW WD(DO I NEED THIS???)
06666 2333 ISZ MSIGN /SHOULD RESULT BE NEGATIVE?
06667 7410 SKP /NO
06670 4543 JMS I [FFNEG /YES-NEGATE IT
06671 1045 TAD ACH
06672 7650 SNA CLA /A ZERO AC MEANS A ZERO EXPONENT
06673 3044 DCA ACX
06674 1021 TAD DFLG
06675 7740 SMA SZA CLA /D.P. INTEGER MODE?
06676 1044 TAD ACX /WITH ACX LESS THAN 0?
06677 7450 SNA
06700 5476 JMP I FPNXT /NO - RETURN
06701 7040 CMA
06702 4541 JMS I [ACSR /UN-NORMALIZE RESULT
06703 5476 JMP I FPNXT /RETURN

```

```

/MDSET-SETS UP SIGNS FOR MULTIPLY AND DIVIDE
/ALSO SHIFTS OPERAND ONE BIT TO THE LEFT.
/EXIT WITH EXPONENT OF OPERAND IN AC FOR EXPONENT
/CALCULATION-CALLED WITH ADDRESS OF OPERAND IN AC AND
/DATA FIELD SET PROPERLY FOR OPERAND.

```

```

06704 0000 MDSET, 0
06705 7344 CLA CLL CMA RAL /SET SIGN CHECK TO -2
06706 3333 DCA MSIGN
06707 1056 TAD OPH /IS OPERAND NEGATIVE?
06710 7700 SMA CLA
06711 5314 JMP .+3 /NO
06712 4774 JMS I [OPNEG /YES-NEGATE IT
06713 2333 ISZ MSIGN /BUMP SIGN CHECK
06714 1057 TAD OPL /AND SHIFT OPERAND LEFT ONE BIT
06715 7104 CLL RAL
06716 3057 DCA OPL
06717 1056 TAD OPH
06720 7004 RAL
06721 3056 DCA OPH
06722 3053 DCA ACI /CLR. OVERFLOW WORF OF FAC
06723 1045 TAD ACH /IS FAC NEGATIVE
06724 7700 SMA CLA
06725 5331 JMP LEV /NO-GO ON
06726 4543 JMS I [FFNEG /YES-NEGATE IT
06727 2333 ISZ MSIGN /BUMP SIGN CHECK
06730 7000 NOP /MAY SKIP
06731 1055 LEV, TAD OPX /EXIT WITH OPERAND EXPONENT IN AC
06732 5704 JMP I MDSET
06733 0000 MSIGN, 0

```

/24 BIT BY 12 BIT MULTIPLY. MULTIPLIER IS IN OPL
 /MULTIPLICAND IS IN ACH AND ACL
 /RESULT LEFT IN MDSET,AC2, AND AC1

06734	0000	MP24,	0		
06735	1373		TAD	(-14	/SET UP 12 BIT COUNTER
06736	3055		DCA	OPX	
06737	1057		TAD	OPL	/IS MULTIPLIER=0?
06740	7440		SZA		
06741	5345		JMP	MPLP1	/NO-GO ON
06742	3053		DCA	AC1	/YES-INSURE RESULT=0
06743	5734		JMP I	MP24	/RETURN
06744	1057	MPLP,	TAD	OPL	/SHIFT A BIT OUT OF LOW ORDER
06745	7010	MPLP1,	RAR		/OF MULTIPLIER AND INTO LINK
06746	3057		DCA	OPL	
06747	7420		SNL		/WAS IT A 1?
06750	5356		JMP	MPLP2	/NO - 0 - JUST SHIFT PARTIAL PROD
06751	1054		TAD	AC2	/YES-ADD MULTIPLICAND TO PARTIAL
06752	1046		TAD	ACL	/LOW ORDER
06753	3054		DCA	AC2	
06754	7024		CML RAL		/*K* NOTE THE "SNL" 5 WORDS BACK!
06755	1045		TAD	ACH	/HI ORDER
06756	1304	MPLP2,	TAD	MDSET	
06757	7010		RAR		/NOW SHIFT PARTIAL PROD. RIGHT 1
06760	3304		DCA	MDSET	
06761	1054		TAD	AC2	
06762	7010		RAR		
06763	3054		DCA	AC2	
06764	1053		TAD	AC1	
06765	7010		RAR		/OVERFLOW TO AC1
06766	3053		DCA	AC1	
06767	2055		ISZ	OPX	/DONE ALL 12 MULTIPLIER BITS?
06770	5344		JMP	MPLP	/NO-GO ON
06771	5734		JMP I	MP24	/YES-RETURN
06773	7764				
06774	7203				
06775	7110				
06776	6514				
06777	6460				
	7000				
					PAGE

/DIVIDE-BY-ZERO ROUTINE - MUST BE AT BEGINNING OF PAGE

07000	2035	DBAD,	ISZ	FATAL	/DIVIDE BY 0 NON-FATAL
07001	4434		JMS I	ERR	/GIVE ERROR MSG
07002	1200		TAD	DBAD	
07003	3044		DCA	ACX	/RETURN A VERY LARGE POSITIVE NUM
07004	7332		AC2000		
07005	5325		JMP	FD	

/FLOATING DIVIDE - USES DIVIDE-AND-CORRECT METHOD

07006	4777	DDDIV,	JMS I	(DARGET	
07007	7410		SKP		
07010	4776	FFDIV,	JMS I	(ARGET	/GET OPERAND
07011	4775		JMS I	(MDSET	/GO SET UP FOR DIVIDE-OPX IN AC
07012	7041		CMA	IAC	/NEGATE EXP. OF OPERAND
07013	1044		TAD	ACX	/ADD EXP OF FAC
07014	3044		DCA	ACX	/STORE AS FINAL EXPONENT
07015	1056		TAD	OPH	/NEGATE HI ORDER OP. FOR USE
07016	7141		CLL CMA	IAC	/AS DIVISOR
07017	3056		DCA	OPH	
07020	4231		JMS	DV24	/CALL DIV.--(ACH+ACL)/OPH
07021	1046		TAD	ACL	/SAVE QUOT. FOR LATER
07022	3053		DCA	AC1	
07023	1057		TAD	OPL	
07024	7650		SNA CLA		
07025	5327		JMP	DVL2	/AVOID MULTIPLYING BY 0
07026	1374		TAD	(-15	/SET COUNTER FOR 12 BIT MULTIPLY
07027	3231		DCA	DV24	/TO MULTIPLY QUOT. OF DIV. BY
07030	5267		JMP	DVLP1	/LOW ORDER OF OPERAND (OPL)

/DIVIDE ROUTINE - (ACH,ACL)/OPH = ACL REMAINDER REM

07031	0000	DV24,	Ø		
07032	1045		TAD	ACH	/CHECK THAT DIVISOR IS .GT.
07033	1056		TAD	OPH	/DIVISOR IN OPH (NEGATIVE)
07034	7630		SZL	CLA	/IS IT?
07035	5200		JMP	DBAD	/NO-DIVIDE OVERFLOW
07036	1374		TAD	(-15	/YES-SET UP 12 BIT LOOP
07037	3054		DCA	AC2	
07040	5251		JMP	DV1	/GO BEGIN DIVIDE
07041	1045	DV2,	TAD	ACH	/CONTINUE SHIFT OF FAC LEFT
07042	7004		RAL		
07043	3045		DCA	ACH	/RESTORE HI ORDER
07044	1045		TAD	ACH	/NOW SUBTRACT DIVISOR FROM HI ORDER
07045	1056		TAD	OPH	/DIVIDEND
07046	7430		SZL		/GOOD SUBTRACT?
07047	3045		DCA	ACH	/YES-RESTORE HI DIVIDEND
07050	7200		CLA		/NO-DON'T RESTORE--OPH.GT.ACH
07051	1046	DV1,	TAD	ACL	/SHIFT FAC LEFT 1 BIT-ALSO SHIFT
07052	7004		RAL		/1 BIT OF QUOT. INTO LOW ORD OF ACL
07053	3046		DCA	ACL	
07054	2054		ISZ	AC2	/DONE 12 BITS OF QUOT?
07055	5241		JMP	DV2	/NO-GO ON
07056	5631		JMP I	DV24	/YES-REIN W/AC2=0

/DIVIDE ROUTINE CONTINUED

07057	3057	MP12L,	DCA	OPL	/STORE BACK MULTIPLIET
07060	1054		TAD	AC2	/GET PRODUCT SO FAR
07061	7420		SNL		/WAS MULTIPLIER BIT A 1?
07062	5265		JMP	.+3	/NO-JUST SHIFT THE PARTIAL PRODUCT
07063	7100		CLL		/YES-CLEAR LINK AND ADD MULTIPLICA
07064	1046		TAD	ACL	/TO PARTIAL PRODUCT
07065	7010		RAR		/SHIFT PARTIAL PRODUCT-THIS IS HI
07066	3054		DCA	AC2	/RESULT-STORE BACK
07067	1057	DVLP1,	TAD	OPL	/SHIFT A BIT OUT OF MULTIPLIER
07070	7010		RAR		/AND A BIT OR RESLT. INTO IT (LO
07071	2231		ISZ	DV24	/DONE ALL BITS?

07072	5257		JMP	MP12L	/NO-LOOP BACK
07073	7141		CLL	CIA	/YES-LOW ORDER PROD. OF QUOT. X
07074	3046		DCA	ACL	/NEGATE AND STORE
07075	7024		CML	RAL	/PROPAGATE CARRY
07076	1054		TAD	AC2	/NEGATE HI ORDER PRODUCT
07077	7161		STL	CIA	
07100	1045		TAD	ACH	/COMPARE WITH REMAINDER OF FIRST
07101	7430		SZL		/WELL?
07102	5331		JMP	DVOPS	/GREATER THAN REM.-ADJUST QUOT OF
07103	3045		DCA	ACH	/OK - DO (REM - (Q*OPL)) / OPH
07104	4231	DVL3,	JMS	DV24	/DIVIDE BY OPH (HI ORDER OPERAND)
07105	1053	DVL1,	TAD	AC1	/GET QUOT. OF FIRST DIV.
07106	7500		SMA		/IF HI ORDER BIT SET-MUST SHIFT 1
07107	5325		JMP	FD	/NO-ITS NORMALIZED-DONE
07110	7100	SHR1,	CLL		
07111	2046		ISZ	ACL	/ROUND AND SHIFT RIGHT ONE
07112	7410		SKP		
07113	7001		IAC		/DOUBLE PRECISION INCREMENT
07114	7010		RAR		
07115	3045		DCA	ACH	/STORE IN FAC
07116	1046		TAD	ACL	/SHIFT LOW ORDER RIGHT
07117	7010		RAR		
07120	3046		DCA	ACL	/STORE BACK
07121	2044		ISZ	ACX	/BUMP EXPONENT
07122	7000		NOP		
07123	1045		TAD	ACH	
07124	5306		JMP	DVL1+1	/IF FRACT WAS 77777777 WE MUST
07125	3045	FD,	DCA	ACH	/STORE HIGH ORDER RESULT
07126	5773		JMP	I (M)DONE	/GO LEAVE DIVIDE
07127	3046	DVL2,	DCA	ACL	/COME HERE IF LOW-ORDER QUO=0
07130	5304		JMP	DVL3	/SAVE SOME TIME

/FORTRAN 4 RUNTIME SYSTEM - R.L PAL8-V8

PAGE 84

/ROUTINE TO ADJUST QUOTINET OF FIRST DIVIDE (MAYBE) WHEN
/REMAINDER OF THE FIRST DIVIDE IS LESS THAN QUOT*OPL

07131	7041	DVOPS,	CMA	IAC	/NEGATE AND STORE REVISED REMAINDER
07132	3045		DCA	ACH	
07133	7100		CLL		
07134	1056		TAD	OPH	
07135	1045		TAD	ACH	/WATCH FOR OVERFLOW
07136	7420		SNL		
07137	5344		JMP	DVOP1	/OVERFLOW-DON'T ADJUST QUOT. OF 1
07140	3045		DCA	ACH	/NO OVERFLOW-STORE NEW REM.
07141	7040		CMA		/SUBTRACT 1 FROM QUOT OF
07142	1053		TAD	AC1	/FIRST DIVIDE
07143	3053		DCA	AC1	
07144	7300	DVOP1,	CLA	CLL	
07145	1045		TAD	ACH	/GET HI ORD OF REMAINDER
07146	7450		SNA		/IS IT ZERO?
07147	3046	DVOP2,	DCA	ACL	/YES-MAKE WHOLE THING ZERO
07150	3045		DCA	ACH	
07151	4231		JMS	DV24	/DIVIDE EXTENDED REM. BY HI DIVISOR
07152	1046		TAD	ACL	/NEGATE THE RESULT
07153	7141		CLL	CMA IAC	
07154	3046		DCA	ACL	
07155	7420		SNL		/IF QUOT. IS NON-ZERO, SUBTRACT
07156	7040		CMA		/ONE FROM HIGH ORDER QUOT.
07157	5305		JMP	DVL1	/GO TO IT

```

07160 0000 LPBUF3, ZBLOCK 12
07172 7316 LPBUF4
07173 6665
07174 7763
07175 6704
07176 6514
07177 6460
7200 PAGE

```

/FORTRAN 4 RUNTIME SYSTEM - R.L PAL8-V8 PAGE 85

/"NRMFAC" AND "OPNEG" MUST BE AT 0 AND 3 ON PAGE

```

07200 3053 NRMFAC, DCA AC1 /KILL OVERFLOW BIT
07201 4271 JMS FPNOR
07202 5476 JMP I FPNXT

07203 0000 OPNEG, 0 /ROUTINE TO NEGATE OPERAND
07204 1057 TAD OPL /GET LOW ORDER
07205 7141 CLL CMA IAC /NEGATE AND STORE BACK
07206 3057 DCA OPL
07207 7024 CML RAL /PROPAGATE CARRY
07210 1056 TAD OPH /GET HI ORDER
07211 7141 CLL CMA IAC /NEGATE AND STORE BACK
07212 3056 DCA OPH
07213 5603 JMP I OPNEG

/
/FLOATING SUBTRACT AND ADD
/
07214 4777 FFSUB, JMS I (ARGET /PICK UP THE OP.
07215 4203 JMS OPNEG /NEGATE OPERAND
07216 7410 SKP
07217 4777 FFADD, JMS I (ARGET /PICK UP OPERAND
07220 1056 TAD OPH /IS OPERAND = 0
07221 7650 SNA CLA
07222 5476 JMP I FPNXT /YES-DONE
07223 1045 TAD ACH /NO-IS FAC=0?
07224 7650 SNA CLA
07225 5236 JMP DOADD /YES-DO ADD
07226 1044 TAD ACX /NO-DO EXPONENT CALCULATION
07227 7141 CLL CMA IAC
07230 1055 TAD OPX
07231 7540 SMA SZA /WHICH EXP. GREATER?
07232 5243 JMP FACR /OPERANDS-SHIFT FAC
07233 7041 CMA IAC /FAC'S-SHIFT OPERAND=DIFFRNC+1
07234 4246 JMS OPSR
07235 4541 JMS I (ACSR /SHIFT FAC ONE PLACE RIGHT
07236 1055 DOADD, TAD OPX /SET EXPONENT OF RESULT
07237 3044 DCA ACX
07240 4537 JMS I (OADD /DO THE ADDITION
07241 4271 JMS FPNOR /NORMALIZE RESULT
07242 5476 JMP I FPNXT /RETURN
07243 4541 FACR, JMS I (ACSR /SHIFT FAC = DIFF.+1
07244 4246 JMS OPSR /SHIFT OPR. 1 PLACE
07245 5236 JMP DOADD /DO ADDITION

```

/OPERAND SHIFT RIGHT-ENTER WITH POSITIVE COUNT-1 IN AC

07246	0000	OPSR,	Ø			
07247	7040		CMA			/- (COUNT+1) TO SHIFT COUNTER
07250	3052		DCA	ACØ		
07251	1056	LOP2,	TAD	OPH		/GET SIGN BIT
07252	7100		CLL			/TO LINK
07253	7510		SPA			
07254	7020		CML			/WITH HI MANTISSA IN AC
07255	7010		RAR			/SHIFT IT RIGHT, PROPAGATING SIGN
07256	3056		DCA	OPH		/STORE BACK
07257	1057		TAD	OPL		
07260	7010		RAR			
07261	3057		DCA	OPL		/STORE LO ORDER BACK
07262	2055		ISZ	OPX		/INCREMENT EXPONENT
07263	7000		NOP			
07264	2052		ISZ	ACØ		/DONE ALL SHIFTS?
07265	5251		JMP	LOP2		/NO-LOOP
07266	7010		RAR			/SAVE 1 BIT OF OVERFLOW
07267	3054		DCA	AC2		/IN AC2
07270	5646		JMP I	OPSR		/YES-RETN.
07271	0000	FFNOR,	Ø			/ROUTINE TO NORMALIZE THE FAC
07272	1045		TAD	ACH		/GET THE HI ORDER MANTISSA
07273	7450		SNA			/ZERO?
07274	1046		TAD	ACL		/YES-HOW ABOUT LOW?
07275	7450		SNA			
07276	1053		TAD	AC1		/LOW=0, IS OVRFLO BIT ON?
07277	7650		SNA	CLA		
07300	5313		JMP	ZEXP		/#=0-ZERO EXPONENT
07301	7332	NORMLP,	CLA	CLL	CML RTR	/NOT 0-MAKE A 2000 IN AC
07302	1045		TAD	ACH		/ADD HI ORDER MANTISSA
07303	7440		SZA			/HI ORDER = 6000
07304	5307		JMP	.+3		/NO-CHECK LEFT MOST DIGIT
07305	1046		TAD	ACL		/YES-6000 OK IF LOW=0
07306	7640		SZA	CLA		
07307	7710		SPA	CLA		/2,3,4,5,ARE LEGAL LEFT MOST DIGS.
07310	5314		JMP	FFNORR		/FOR NORMALIZED #-(+2000=4,5,6,7)
07311	4534		JMS I	[ALIBMP		/SHIFT AC LEFT AND BUMP ACX DOWN
07312	5301		JMP	NORMLP		/GO BACK AND SEE IF NORMALIZED
07313	3044	ZEXP,	DCA	ACX		
07314	3053	FFNORR,	DCA	AC1		/DONE W/NORMALIZE - CLEAR AC1
07315	5671		JMP I	FFNOR		/RETURN
07316	0000	LPBUF4,	ZBLOCK	60		
07376	7400		LPBUFE			
07377	6514					
	7400		PAGE			


CHAPTER 5

LIBRA AND FORLIB

The binary output of an assembly under RALF is called a RALF module. Every RALF module consists of an External Symbol Dictionary (or ESD) and associated text. The ESD lists all global symbols defined in the assembly, while the text contains the actual binary output along with relocation data.

There are three major classes of global symbols. Entry points are global symbols defined in a module and referenced by code in other modules. Thus, entry points include the names of all modules and the names of all globally callable subroutines within modules. Externs are global symbols that are referenced in a module but not defined in that module. For example, the entry point of module A would appear as an extern if referenced in module B. The COMMON area comprises a third class of global symbols including all global symbols which define COMMON.

A FORTRAN IV library is a specially formatted file, created with LIBRA, consisting of a library catalog (which lists section names and entry points of library modules) and a set of RALF modules, perhaps interspersed with empty subfiles. The loader uses one such library, specified by the user, to resolve externs while building a loader image file. The general structure of a FORTRAN IV library is:



LIBRA is a very simple program, basically a file-to-file copy inside several nested loops. The outer loop begins at START, and calls the command decoder for specification of the library and input files. If no library is specified, the previous library name is used (initially this is SYS:FORLIB.RL). If a new name is given, but no extension is specified, .RL is forced. A check is made to verify that the specified library is on a file-structured device, and the handler is FETCHed.

At ZTEST, the /Z switch is tested. If it was set, control passes to NEWLIB to create a new library. Otherwise, an attempt is made to find an old library of the specified name on the device. If it fails, control passes to NEWLIB. Otherwise, the catalog of the old library is read and scanned to determine the starting block of available space. This is stored at LAVAIL. Control then passes to GETINF to begin reading input files.

If /Z was set, or the specified library isn't found, a new library is entered at NEWLIB, and an empty catalog is written. Control passes to GETINF. There, a check is made to determine whether input is presently coming from another library. If it is, control passes to INLIB to obtain the next module from the library. Otherwise, the next input file is obtained from the command decoder area in field 1, and if one exists, control passes to FTCHIN to load the handler. If there is none, the /C switch is tested. If it is not set, control is passed to LCLOSE to close the library. If it is set, however, the command decoder is recalled to obtain a continuation of the preceding input line, and control returns to NXTINF to look in the command decoder area.

At FTCHIN, the unit, starting block, and length of the next input file are obtained from the command decoder area, the appropriate device handler is fetched, and at LUKMOD, the input file is read to ensure that it is either a module or a library. If a library, control passes to GOTLIB, which sets INLSW and goes to INLIB to obtain the first module from the library. Otherwise, the length is checked against the available length in the library, to ensure that this module can be fit in, and control goes to NXTEBK to read the ESD.

At INLIB, the catalog of the library being input is read, and scanned until a module is found with a starting block greater than the starting block of the last input module (in the case of the first module in a library, MODBLK, which normally contains the starting block of a module, contains the starting block of the library, so this scan yields the starting block of the first module in the library). When the next module has been found, control returns to LUKMOD to check the length of the module against the available length in the library.

At NXTEBK, the end of the input module is scanned for entry point and section names. Whenever one is found, the catalog of the output library is scanned for a matching name. If a match is found, control passes to GOTMAT, which prints the duplicated name, and if the /I switch is set, asks the operator which name to keep. If he types N, for new, control passes to DLETO to delete the old name. Otherwise, control is passed to ESDLND to find the next entry point or section name in the input. If /I is not set, /R is tested. If it is not set, control is passed to ESDLND. If it is, control flows into DELTO, where the old name is cleared, and the rest of the catalog is scanned to find the first available name slot. Control then passes to INSERT.

If no match was found, the /I switch is tested. If it was set, the operator is asked whether to include the name. If he types, N, for no, control is passed to ESDLND. Otherwise, or if /I was not set, a pointer is set up for the new name, and control passes to INSERT, where the new name is added to the catalog.

When the entire ESD has been scanned, INCLUD is tested to determine whether any name has been included in the catalog, and assuming at least one has, the module is copied into the library, and LAVAIL is updated to indicate the next available block in the library. Control returns to GETINF for another module.

LCLOSE receives control whenever the end of the input file string is reached and /C is not set. Here, any remaining changes in the library catalog are written, and if a new library was entered, it is closed. Control passes to CATLST, to create a catalog listing. The second output file, if any was specified, is opened, a title is output to it, and at PRCAT, the entire contents of the catalog are listed. When this process is complete, the output file is closed, and control returns to start for more command decoder input.

User-coded modules may be added to the system library or incorporated in a new library provided that entry points, variable storage allocations, calling sequences, error conditions and the like are handled with care.

Every library module must have a unique section (and entry) name(s). The library supplied by DEC uses the character # before names where duplication in the FORTRAN program may be possible. Note that this character is acceptable to RALF, but is illegal in a FORTRAN source. If more than one entry is required to the routine, they should be listed as such using the pseudo-op ENTRY before they are encountered as tags in the code. Thus, if a double precision tangent routine is being written, it may be helpful to have an entry for a double precision co-tangent calculation also. Appropriate code would be:

```
SECT DTAN
JA #DTAN
ENTRY DCOT
JA #DCOT
:
:
#DCOT,
:
:
#DTAN,
```

When routines will handle double precision or complex values, allocate six words for their storage. Such routines can switch between the STARTF (3 word format) and STARTE (6 word format) pseudo-ops as required, being careful to define variables of the proper length to keep track of temporary locations.

All user-written library routines are called by a JSR in STARTF mode. Depending on the type of function, the routine must be coded to exit as follows in order to return the result to the program:

Single precision (integer, real and logical) Answer in AC in STARTF mode

```

      FLDA ANSWER      /In STARTF mode
      JA RETURN       /3 word result

```

Double precision: Answer in AC in STARTE mode

```

      FLDA ANSWER      /In STARTE mode
      JA RETURN       /6 word result

```

Complex: Answer in location #CAC in STARTE mode

```

      EXTERN #CAC      /Real part in first 3 words
      STARTE          /Imaginary in last 3 words
      FLDA ANSWER      /Exit in STARTE mode
      FSTA #CAC       /6 word result
      JA RETURN

```

Routines should conform to the FPP FORTRAN calling sequence. An example of that sequence follows:

```

      SECT DTAN        /Sector name
      JA #DTAN        /Jump to Start of Function
      TEXT +DTAN +    /6 characters for trace
                    /back feature must be
                    /immediately before index
                    /register assignment.
DTANXR, SETX XRDTAN  /This tag referenced when
                    /returning to reset base
                    /page and index registers
                    /if this routine called.

      SETB BPDTAN

BPDTAN, F 0.0        /3 words each
XRDTAN, F 0.0        /These locations may be
                    /used for temporary storage or
                    /If this routine is called,
                    /will set up return to it.

      FNOP
      JA DTANXR
      0
DTNRTN, JA .        /Return to calling program
      BASE 0        /Still on caller's base page
#DTAN,  STARTD      /Start of subroutine
      FLDA 10*3     /Get jump to caller's return jump
      FSTA DTNRTN  /Save for return from this routine

```

```

FLDA 0 /Get next location in caller's
/routine (pointer to argument list)
SETX XRDTAN /Change index registers to this
/routine's
SETB BPDATAN /Change base page to this routine's
BASE BPDATAN /Change base page to this routine's
FSTA TEMP /Save pointer
LDX 1,1 /Set up XRL
FLDA% TEMP,1 /Get address of argument list
FSTA TEMP /Save it
STARTE /A double precision routine
FLDA% TEMP /Get variable
FSTA TEMP /Save variable
.
.
. /Calculate result
.
.
FLDA ANSWER /Load answer
JA DTNRTN /Exit

```

The following conventions must be observed to return to the calling program at the correct location, to permit the error trace back feature to function properly, and to preserve index registers and base page integrity.

Locations 0 and 30 of the called (user-coded) program are determined by a statement in the form `ORG 10*3+BPAGE` which must be followed by a two-word jump to the index register and base page assignment instructions `JA BPIXR`. In the above example, the code is:

```

ORG 10*3+BPDATN
FNOP
JA DTANXR

```

By saving the contents of location 30 of the calling program (`FLDA 10*3,FSTA RETURN`) for the return exit, the called program executes (when control is returned to it) a `JA BPIXR` to its base page and index register assignment statement. In the calling program this resets the index registers and base page and then returns to execute the instruction in the calling program. In the tangent example above, the code is:

```
FLDA 10*3
FSTA DTNRTN
```

which creates the instruction

```
JA xxx
```

at the tag DTNRTN, where xxx is the location in the calling routine whose function corresponds to DTANXR in DTAN.

When called, the routine must assign its own base page and index registers (SETX XROWN, SETB BPOWN). If arguments are to be passed to the called routine, a scheme such as illustrated above permits any number of arguments to be passed from the calling program and saved on the base page of the called program, in this case just two arguments.

The corresponding code for the calling program (as created by the compiler) is:

```
EXTERN DTAN
JSR DTAN
JA .+4           /Jump past all arguments
JA A            /Argument
:
:
FSTA Q          /Save result in some variable
```

The FORTRAN for such code is:

```
Q = DTAN (A)
```

The calling sequence is also discussed in Chapter 2.

To permit the error trace back feature to function properly, a TEXT statement followed by a six alphanumeric character name is required immediately before the index register and base page assignment statements. Thus, if the cotangent routine includes a JSR TAN and an

unacceptable argument is passed to the tangent function, the trace back indicates the location of the problem by a sequence such as:

```
DIV0 MAIN
ARGUMENT
7777 SIN
0000 TAN
0000 COT
0007 MAIN
```

(Line numbers are not relevant in RALF modules such as TAN and SIN: they are meaningful only in FORTRAN source programs.)

A new library routine may call other new or existing library routines as part of its function, as well as the error handling function of the run-time system. To invoke the error message program, code such as the following is required:

```
                EXTERN    #ARGER
MERROR, TRAP4   #ARGER
```

Then any condition encountered in the program that is an error should jump to MERROR. For example, if an argument of ≤ 0 is illegal, it could be examined and handled as follows:

```
FLDA%  ARG2
JLE    MERROR    /<0 error
FSTA  NEXT      / Save non-zero value
```

In this case, the TRAP4 #ARGER at MERROR will produce the message BAD ARG DTAN nnnn followed by traceback and program termination. If a new library routine would like to use an existing library routine, a JSR to that routine is required. The sequence for passing arguments is:

```
EXTERN  ATAN2
JSR     ATAN2
JA      .+6      /Execute upon exit from
JA      A        /1st arg
JA      B        /2nd arg
FSTA    ANSWER   /Save answer
```

The arguments must be referenced in the order expected by the called routine and must agree in number and type. The following routines can be used in this manner:

<u>ROUTINE</u>	<u>ARGUMENTS PASSED</u>
AMOD	Address of X then Y
SQRT	Address of X
ALOG10	Address of X
EXP	Address of X
SIN	Address of X
COS	Address of X
TAN	Address of X
SIND	Address of X
COSD	Address of X
TAND	Address of X
ASIN	Address of X
ACOS	Address of X
ATAN	Address of X
ATAN2	Address of X then Y
SINH	Address of X
COSH	Address of X
TANH	Address of X
DMOD	Address of X then Y
DSIGN	Address of X then Y
DSIN	Address of X
DLOG	Address of X
DSQRT	Address of X
DCOS	Address of X
DLOG10	Address of X
DATAN2	Address of X then Y
DATAN	Address of X
DEXP	Address of X
CMPLX	Address of X
CSIN	Address of X
CCOS	Address of X
REAL	Address of X
AIMAG	Address of X
CONJG	Address of X
CEXP	Address of X
CLOG	Address of X
CABS	Address of X
CSQRT	Address of X

For real and double precision routines, the result is returned via the FAC (3 or 6 words, respectively). For complex routines, the result is returned in #CAC (6 words).

The TAN function from FORLIB is included here as an example of the requirements just discussed. The TAN function calls two external functions, has the standard calling sequence, and contains an error condition exit.

```

/      T A N
/      - - -
/
/SUBROUTINE      TAN(X)
      SECT      TAN          /SECTION NAME
      JA        #TAN        /JUMP AROUND BASE PAGE

TANER,  EXTERN  #ARGER      /EXIT TO ERROR MESSAGE HANDLER
      TRAP4    #ARGER      /FOR ERROR TRACE BACK
      TEXT    +TAN  +
TANXR,  SETX   XRTAN       /START OF FORMAL CALLING SEQUENCE
      SETB   BPTAN
BIAN,   FNOP
      0
      0
XRTAN,  F 0.0          /INDEX REGISTERS
TAN1,   F 0.0          /LOCATIONS 21-42 OCTAL AVAILABLE
      /FOR USER STORAGE
TAN2,   F 0.0
      ORG     10+3+BPTAN  /SET UP FOR A RETURN
      /TO THIS ROUTINE
      FNOP
      JA     TANXR       /JUMP TO XR + RP ASSIGNMENT
      0
TANRTN, JA          .
      BASE   0
# TAN,  STARTD
      FLDA   10*3        /SAVE RETURN JUMP
      FSTA   TANRTN
      FLDA   0
      /GET NEXT LOCATION
      /IN CALLING PROGRAM
      SETX   XRTAN       /SET UP FOR TAN'S INDEX REGS
      SETB   BPTAN      /SET UP FOR TAN'S BP
      BASE   BPTAN
      LDX   1,1
      FSTA   BPTAN
      FLDAZ  BPTAN,1    /GET ADDRESS OF X
      FSTA   BPTAN
      STARTF
      FLDAZ  BPTAN      /GET X
      JEQ   TANRTN     /IF 0 RETURN NOW
      FSTA   TAN1      /SAVE FOR A SECOND
      EXTERN COS
      JSR   COS        /TAKE COS(X)
      JA   .+4         /JUMP AROUND ARGUMENT LIST
      JA   TAN1        /REFERENCE TO PASSED ARGUMENT
      JEQ   TANER      /COS=0. A NO-NO
      FSTA   TAN2      /SAVE IT
      EXTERN SIN
      JSR   SIN        /NOW TAKE SJN(X)
      JA   .+4         /JUMP AROUND ARGUMENT LIST
      JA   TAN1        /REFERENCE TO ARGUMENT
      FDIV  TAN2        /DIV BY COS(X)
      JA   TANRTN     /EXIT

```

The library routine ONQI illustrates many of the same conventions. This listing may also prove valuable as a guide to interfacing with the run-time system.

```

FIELD1 ONQI /ROUTINE TO ADD A
/HANDLER TO INTERRUPT SKIP CHAIN
/PUT THIS CODE IN FIELD 1
0
JMP SETINT /SET UP INT INITIALLY
ISZ ONQI /BUMP ARGUMENT POINTER
ISZ INTQ+1 /BUMP INTERRUPT Q POINTER
DCAZ INTQ+1 /STICK IOT ONTO INT Q
TAD XSKP /FOLLOWED BY A SKIP
ISZ INTQ+1
DCAZ INTQ+1 /ONTO INT Q
ISZ ONQI /SKIP FIRST WORD OF ADDR
ISZ INTQ+1
ONQISW, TADZ ONQI /GET INT HANDLER ADDRESS
ISZ ONQI
DCAZ INTADR+1 /ONTO ADDRESS STACK
TAD INTADR+1 /NOW MAKE JMSZ
AND L177
TAD L4600
DCAZ INTQ+1 /ONTO INT Q
ISZ INTADR+1
ISZ IQSIZE /ROOM FOR MORE?
JMPZ ONQI /YES
TAD -1 /NO, CLOSE OUT THE SUBR
DCA ONQI+1
JMPZ ONQI
SETINT, TAD ONQISW /DO THIS PART ONLY ONCE
DCA ONQI+1
CDF
TAD XSKP /FIX UP #INT
DCAZ XINT+1 /PUT SKIP INST. FIRST
ISZ XINT+1
TAD INTQ+1
DCAZ XINT+1 /GET ADDR. OF USER'S ROUTINE
ISZ XINT+1 /ADD TO INTERRUPT CALL
TAD CIFCDF /GET FIELD INSTRUCTION
/FIELD1 SECTION INSURES ITS IN FIELD 1
CIFCDF, CDF CIF 10
JMP ONQI+1 /BACK TO ONQI
EXTERN #INT
XINT, ADDR #INT /POINTS TO INT RTN IN COMMON
INTQ, ADDR IHANDL /MUST USE 15 BIT ADDRESS
INTADR, ADDR IHADRS /
IQSIZE, -5
XSKP, SKP
L177, 177
L4600, 4600
CDF CIF
JMPZ IHANDL
IHANDL, 0
REPEAT 16
JMP IHANDL-2
IHADRS, 0;0;0;0;0 /CAN SET UP 1-5 DEVICES

```

```

ENTRY ONQB /USE "ENTRY" TO PERMIT
/ACCESS FROM OUTSIDE OF SECTION
/ROUTINE TO SET UP AN IDLE JOB
ONQB, 0
      JMP SETBAK /SETUP #IDLE
      TADZ ONQB /GET ADDRESS OF IDLE JOB
ONQBSW, ISZ ONQB
      DCAZ BAKADR+1 /STORE ONTO BACKGROUND JOB Q
      TAD BAKADR+1 /MAKE A JMSZ
      ISZ BAKADR+1
      AND L177
      TAD L4600
      ISZ BAKQ+1
      DCAZ BAKQ+1
      ISZ BQSIZE /MORE ROOM?
      JMPZ ONQB /YES
      TAD .-1 /NO, CLOSE THE DOOR
      DCA ONQB+1
      JMPZ ONQB
SETBAK, TAD ONQBSW /CLOSE OFF #IDLE INITIALIZATION
      DCA ONQB+1
      CDF
      TAD XSKP /FIX UP #IDLE
      DCAZ XIDLE+1 /ADD SKIP TO IDLE CALL
      TAD BAKQ+1 /GET ADDRESS OF ROUTINE
      ISZ XIDLE+1
      DCAZ XIDLE+1
      ISZ XIDLE+1
      TAD CIFCDF /GET FIELD INSTR.
      DCAZ XIDLE+1
      CIF CDF 10
      JMP ONQB+1
XIDLE, EXTERN #IDLE /EXTERNAL REFERENCE
      ADDR #IDLE
BAKQ, ADDR BAKRND
BAKADR, ADDR BHADRS
BQSIZE, -5
      CDF CIF
      JMPZ BAKRND
BAKRND, 0
      REPEAT 6
      JMP BAKRND-2
BHADRS, 0;0;0;0 /1-5 JOBS

```


APPENDIX A
RALF Assembler Permanent Symbol Table

<u>Mnemonic</u>	<u>Code</u>		
FPP Memory Reference Instructions			
FADD	1000	SETB	1110
FADDM	5000	SETX	1100
FDIV	3000	STARTD	0006
FLDA	0000	STARTE	0050
FMUL	4000	STARTF	0005
FMULM	7000	TRAP3	3000
FSTA	6000	TRAP4	4000
FSUB	2000	TRAP5	5000
		TRAP6	6000
IOT'S		TRAP7	7000
		XTA	0030
FPINT	6551		
FPICL	6552	Pseudo-Operators	
FPCOM	6553	ADDR	
FPHLT	6554	BASE	
FPST	6555	COMMON	
FPRST	6556	COMMZ	
FPIST	6557	DECIMAL	
8-Mode Memory Reference Instructions			
AND	0000	DPCHK	
TAD	1000	E	
ISZ	2000	END	
DCA	3000	ENTRY	
JMS	4000	EXTERN	
JMP	5000	F	
IOT	6000	FIELD1	
OPR	7000	IFNDEF	
		IFNEG	
		IFNZRO	
		IFPOS	
		IFREF	
		IFZERO	
		INDEX	
		LISTOFF	
		LISTON	
		OCTAL	
		ORG	
		REPEAT	
		SECT	
		SECT8	
		TEXT	
		ZBLOCK	
		IFFLAP	
		IFRALF	
		IFSW	
		IFNSW	
FPP Special Format Instructions			
ADDX	0110		
ALN	0010		
ATX	0020		
FCLA	0002		
FEXIT	0		
FNEG	0003		
FNOP	0040		
FNORM	0004		
FPAUSE	0001		
JA	1030		
JAC	0007		
JAL	1070		
JEQ	1000		
JGE	1010		
JGT	1060		
JLE	1020		
JLT	1050		
JNE	1040		
JSA	1120		
JSR	1130		
JXN	2000		

APPENDIX B

ASSEMBLY INSTRUCTIONS

The following sequence of commands may be used to assemble the OS/8 FORTRAN IV system programs. It is assumed that all PAL language sources reside on DSK. In this example, DTAL is shown as the target device, however any other device could be used via the appropriate ASSIGN command. Note that PASS20.SV is produced by conditional assembly of PASS2.PA and that the "0" in PASS20 is an oh, not a zero. The initial dot and asterisk characters on every command line shown are printed by the monitor. All other characters (except carriage return, in some cases) are typed by the user. Type CTRL/Z after each of the three system pauses at point ①, to continue assembly of PASS20. Type ALT MODE to produce the "\$" character.

```
.ASSIGN DTAL DEV
.R PAL8
*F4.BN,LIST.LS<F4$
.R ABSLDR
*F4$
.SAVE DEV F4=0;12200$
.R PAL8
*PASS2.BN,LIST.LS<PASS2$
.R ABSLDR
*PASS2$
.SAVE DEV PASS2=0;5000$
.R PAL8
*PASS20.BN,LIST.LS<TTY:,DSK:PASS2$OVERLY=1
```

①

```
.R ABSLDR
.PASS20$
.SAVE DEV PASS20=0;7605$
.R PAL8
*PASS3.BN,LIST.LS<PASS3$
.R ABSLDR
*PASS3$
.SAVE DEV PASS3=0;400$
.R PAL8
*RALF.BN,LIST.LS<RALF$
.R ABSLDR
*RALF$
.SAVE DEV RALF=0;200$
.R PAL8
*LOAD.BN,LIST.LS<LOAD$
.R ABSLDR
*LOAD$
.SAVE DEV LOAD=0;200
.R PAL8
*FRTS.BN,LIST.LS<RTS,RTL$
.R ABSLDR
*FRTS$
.SAVE DEV FRTS=0;200
.R PAL8
*LIBRA.BN,LIST.LS<LIBRA$
.R ABSLDR
*LIBRA$
.SAVE DEV LIBRA=0;200
.
```


INDEX

Argument passing, 2-10
 Arithmetic expression
 analyser, 1-2

 Background jobs, 4-1
 Binary buffer table, 3-8
 Binary section table, 3-10
 Block count sequence number, 4-14

 COMMON information block, 1-7
 Communication, 2-9
 COMMZ sections, 2-12
 Compilation, 1-1
 Compiler symbol table, 1-2

 Device handlers, 4-16
 Defice flag handlers, 4-2
 Dimension information block, 1-5
 DSRN table, 4-8

 Entry point, 2-1
 EQUIVALENCE information table,
 1-7
 ESD, 2-1, 2-5, 2-6
 ESD correspondence table, 3-8
 External symbol, 2-1
 External symbol dictionary, 2-1,
 2-5, 2-6

 FIELD1 sections, 2-13
 Files, 4-13
 Formatted I/O, 4-13
 FRTS
 Calling sequence, 4-4
 Core maps, 4-6
 Entry points, 4-5
 Initialization, 4-14
 Page zero, 4-10

 Header block, 3-13

 Idle jobs, 4-1
 Indirect addressing, 2-7
 Interrupts,
 Servicing, 4-1, 4-15
 Spurious, 4-15

 Keyword, 1-2

 LIBRA, 5-2
 Library, 2-1
 Format, 5-1
 Line printer handler, 4-14
 Literals, 1-4, 1-5
 Loader, 3-1
 Core maps, 3-2 to 3-4
 Image file, 3-12
 Subroutines, 3-3

 Loader symbol table, 3-1, 3-7
 Magic number, 1-6
 Mixing code, 2-8
 Module, 2-1
 Module count table, 3-12
 Module descriptor table, 3-11

 Off-page references, 2-19
 Optimized code, 2-11
 Output codes, 1-7
 Overlay table, 3-10

 /P option, 4-21
 Page boundaries, 2-18
 PASS1, 1-1
 Output, 1-7
 Subroutines, 1-10
 PASS2, 1-12
 Error list, 1-14
 Skeleton tables, 1-14
 Symbol table, 1-14
 Subroutines, 1-15
 PASS3, 1-17
 PDP-8 code, 2-7
 Program loading, 3-9
 Program termination, 4-2
 Pseudo-ops, 2-7

 RALF, 2-1
 Expressions, 2-4
 Symbol table, 2-5
 RALF output file, 2-6

 Section, 2-1
 Section types, 2-11
 Statement number, 1-4
 Subroutine calls, 2-9
 Subroutine return sequence, 2-10
 Symbol table,
 Compiler, 1-14
 Loader, 3-7
 RALF, 2-5

 Termination, program, 4-22
 Text, 2-1
 TRAP3 and TRAP4, 2-8

 Variable type word, 1-3

 8-mode sections, 2-14

READER'S COMMENTS

Digital Equipment Corporation maintains a continuous effort to improve the quality and usefulness of its publications. To do this effectively we need user feedback--your critical evaluation of this document.

Did you find errors in this document? If so, please specify by page.

How can this document be improved?

How does this document compare with other technical documents you have read?

Job Title _____ Date: _____

Name: _____ Organization: _____

Street: _____ Department: _____

City: _____ State: _____ Zip or Country _____

-----**Fold Here**-----

-----**Do Not Tear - Fold Here and Staple**-----

FIRST CLASS
PERMIT NO. 33
MAYNARD, MASS.

BUSINESS REPLY MAIL
NO POSTAGE STAMP NECESSARY IF MAILED IN THE UNITED STATES

Postage will be paid by:

digital

Digital Equipment Corporation
Software Information Service
Software Engineering and Services
Maynard, Massachusetts 01754

